

Euro Ford V42.10Diagnostics List(Note:For reference only)

menu select	Year	Model	PCM	TCM	ABS	RCM/IAB	BCMII/GEM	ICM/IPC	EATC/HVAC	NAV	EPS	PAM/PBM	ACM	DDM	PDM	RLDM	RRDM	RK E	HCM	GDM	PATS/CSM	HEC	CDP	FACM	EPB	AHCM	CCMII/ICCM	CMR	DSM	ECS	FFH	FIP	ICU	RETM	RFA	RHI D	SRM	TBM	TRM	VDM
-------------	------	-------	-----	-----	-----	---------	-----------	---------	-----------	-----	-----	---------	-----	-----	-----	------	------	------	-----	-----	----------	-----	-----	------	-----	------	------------	-----	-----	-----	-----	-----	-----	------	-----	-------	-----	-----	-----	-----

Note:

C:DTC reading and clearing
D:Data Display
T:Action Test
PMI:Programmable module installation
PATS:Passive anti theft system functions
FICF:Fuel Injector Correction Factors
OW:Odometer write
KP:Key Program
IP:Injector program
DPF:Diesel Particulate Filter Reset and Regeneration
ESC:ESP sensor calibration
EPBC:EPB calibration
SF:Service Functions
TPMS:TPMS Reset
BC:BCMii Configuration
RC:RCM Configuration
RFAT:Refill the fuel Additives tank
LCTP:Learn Clutch Touch Point
ASB:ABS service bleed
IVD:IVD Initialization Sequence

(*):Tested;
(?):Manual on website(www.x431.com)

All description rights reserved by LAUNCH TECH.CO.,LTD
元征公司保留最终解释权