

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	COLT	ENGINE	√	√	√	√	√		
JAPAN	COLT	AT	√	√	√	√	√		
JAPAN	COLT	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
JAPAN	COLT	AC	√	√	√	√	√		
JAPAN	COLT	SRS	√	√	√	√	√		
JAPAN	COLT	SWS	√	√	√	√	√		
JAPAN	COLT	METER	√	√	√	√	√		
JAPAN	COLT	ETACS	√	√	√	√	√		
JAPAN	COLT	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	COLT	Power Gate	√	√	√	√			
JAPAN	COLT PLUS	ENGINE	√	√	√	√	√		
JAPAN	COLT PLUS	AT	√	√	√	√	√		
JAPAN	COLT PLUS	ABS	√	√	√	√	√		
JAPAN	COLT PLUS	SRS	√	√	√	√	√		
JAPAN	COLT PLUS	SWS	√	√	√	√	√		
JAPAN	COLT PLUS	AC	√	√	√	√	√		
JAPAN	COLT PLUS	METER	√	√	√	√	√		
JAPAN	COLT PLUS	ETACS	√	√	√	√	√		
JAPAN	COLT PLUS	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	COLT PLUS	POWER GATE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA D:5	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	DELICA D:5	AT	√	√	√	√		1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	
JAPAN	DELICA D:5	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.SAS calibration(*)	
JAPAN	DELICA D:5	SRS	√	√	√	√	√		
JAPAN	DELICA D:5	AC	√	√	√	√	√		
JAPAN	DELICA D:5	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA D:5	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
JAPAN	DELICA D:5	SAS	√	√	√			1.SAS calibration(*)	
JAPAN	DELICA D:5	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration(*) 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	DELICA D:5	AUTO CRUISE	√	√	√	√			
JAPAN	DELICA D:5	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	DELICA D:5	CAMERA	√	√	√	√			
JAPAN	DELICA D:5	POWER GATE	√	√	√	√	√		
JAPAN	DELICA D:5	AND	√	√	√				
JAPAN	DELICA D:5	LIN	√	√	√	√		Rain sensor adaptation	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA D:5	ELECTRIC SLIDE DOOR R	√	√	√	√	√		
JAPAN	DELICA D:5	ELECTRIC SLIDE DOOR L	√	√	√	√	√		
JAPAN	DELICA D:5	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	DELICA D:5	AS&G	√	√	√	√			
JAPAN	DELICA D:5	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	DELICA SPACE GEAR	ENGINE	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	AT	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	ABS	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	SRS	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	AC	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	ETACS	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	ECS	√	√	√	√	√		
JAPAN	DELICA VAN / CARGO /TRUCK	ENGINE	√	√	√	√	√		
JAPAN	DELICA VAN / CARGO /TRUCK	AT	√	√	√	√	√		
JAPAN	DELICA VAN / CARGO /TRUCK	ABS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA VAN / CARGO /TRUCK	METER	√	√	√	√	√		
JAPAN	EK-SPACE	ENGINE	√	√	√	√			
JAPAN	EK-SPACE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
JAPAN	EK-SPACE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
JAPAN	EK-SPACE	AC	√	√	√	√			
JAPAN	EK-SPACE	SRS	√	√	√	√			
JAPAN	EK-SPACE	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	EK-SPACE	ETACS	√	√	√	√			
JAPAN	EK-SPACE	IMMO	√	√	√	√	√	1.Keyless ID Registration 2.Keyless Reception Check 3.KOS key registration 4.Forced power supply output 5.Forced power supply output(stop) 6.Engine switch control	CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-SPACE	4WS/Electric Power Steering	√	√	√	√			
JAPAN	EK-SPACE	SAS	√	√	√	√			
JAPAN	EK-SPACE	ELECTRIC SLIDE DOOR R	√	√	√	√			
JAPAN	EK-SPACE	ELECTRIC SLIDE DOOR L	√	√	√	√			
JAPAN	EK-SPACE	AFS/ACL	√	√	√	√			
JAPAN	EK-SPACE	Assist Battery	√	√	√	√			
JAPAN	EK-SPACE	Multi Around Monitor	√	√	√	√	√	1. Write Learned value(Changed ECU) 2. Front & Top view forced display 3. Calibration maker range display 4. Calibration	
JAPAN	EK-WAGON(B11W)	ENGINE	√	√	√	√			
JAPAN	EK-WAGON(B11W)	AT	√	√	√	√		1. Emission gas mode 2. CVT oil degradation level 3. Sensor calibration 4. Electronic oil pump air bleeding 5. Reset	
JAPAN	EK-WAGON(B11W)	ABS	√	√	√	√	√	1. Emission gas mode 2. Sensor calibration	
JAPAN	EK-WAGON(B11W)	AC	√	√	√	√			
JAPAN	EK-WAGON(B11W)	SRS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-WAGON(B11W)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	EK-WAGON(B11W)	ETACS	√	√	√	√			
JAPAN	EK-WAGON(B11W)	IMMO	√	√	√	√	√	1.Keyless ID Registration 2.Keyless Reception Check 3.KOS key registration 4.Forced power supply output 5.Forced power supply output(stop) 6.Engine switch control	CODING
JAPAN	EK-WAGON(B11W)	4WS/Electric Power Steering	√	√	√	√			
JAPAN	EK-WAGON(B11W)	SAS	√	√	√	√			
JAPAN	EK-WAGON(B11W)	AFS/ACL	√	√	√	√			
JAPAN	EK-WAGON(H81W)	ENGINE	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	AT	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	ABS	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	SRS	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	SWS	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	ENGINE	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	AT	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	ABS	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	SRS	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	SWS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	GALANT FORTIS	AT	√	√	√	√		1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-In 5.Emission gas mode	
JAPAN	GALANT FORTIS	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.SAS calibration(*)	
JAPAN	GALANT FORTIS	SRS	√	√	√	√	√		
JAPAN	GALANT FORTIS	AC	√	√	√	√	√		
JAPAN	GALANT FORTIS	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
JAPAN	GALANT FORTIS	SAS	√	√	√			SAS calibration	
JAPAN	GALANT FORTIS	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration(*) 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	GALANT FORTIS	AUTO CRUISE	√	√	√	√			
JAPAN	GALANT FORTIS	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	GALANT FORTIS	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS	AYC/ACD	√	√	√	√		1.Sensor calibration(*) 2.Air bleeding 3.Test	
JAPAN	GALANT FORTIS	AND	√	√	√				
JAPAN	GALANT FORTIS	LIN	√	√	√	√		Rain sensor adaptation	
JAPAN	GALANT FORTIS	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	GALANT FORTIS	AUDIO	√	√	√	√			
JAPAN	GALANT FORTIS	SHIFT LEVER	√	√	√	√	√		
JAPAN	GALANT FORTIS	AS&G	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	GALANT FORTIS SPORTBACK	AT	√	√	√	√		1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-In 5.Emission gas mode	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS SPORTBACK	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.SAS calibration(*)	
JAPAN	GALANT FORTIS SPORTBACK	SRS	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	AC	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
JAPAN	GALANT FORTIS SPORTBACK	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
JAPAN	GALANT FORTIS SPORTBACK	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration(*)	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS SPORTBACK	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	GALANT FORTIS SPORTBACK	AUTO CRUISE	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	4WS/ELECTRIC POWER STEERING	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
JAPAN	GALANT FORTIS SPORTBACK	AYC/ACD	√	√	√	√		1.Sensor calibration(*) 2.Air bleeding 3.Test	
JAPAN	GALANT FORTIS SPORTBACK	AND	√	√	√				

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	
JAPAN	GALANT FORTIS SPORTBACK	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	GALANT FORTIS SPORTBACK	AUDIO	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	SHIFT LEVER	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	AS&G	√	√	√	√			
JAPAN	GRANDIS	ENGINE	√	√	√	√	√		
JAPAN	GRANDIS	AT	√	√	√	√	√		
JAPAN	GRANDIS	ABS	√	√	√	√	√		
JAPAN	GRANDIS	SRS	√	√	√	√	√		
JAPAN	GRANDIS	SWS	√	√	√	√	√		
JAPAN	GRANDIS	AC	√	√	√	√	√		
JAPAN	GRANDIS	METER	√	√	√	√	√		
JAPAN	GRANDIS	ETACS	√	√	√	√	√		
JAPAN	GRANDIS	SAS	√	√	√			SAS calibration	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GRANDIS	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number)(*) 3.ENG key code&Chassis No.registration 4.Change password(*)	1.CODING
JAPAN	GRANDIS	AUTO CRUISE	√	√	√	√	√		
JAPAN	GRANDIS	CAMERA	√	√	√	√	√		
JAPAN	GRANDIS	POWER GATE	√	√	√	√			
JAPAN	GRANDIS	DISPLAY	√	√	√				
JAPAN	GRANDIS	KEYLESS OPERATION	√	√	√				
JAPAN	GRANDIS	MULTI SELECT 4WD	√	√	√	√	√		
JAPAN	I(アイ)	ENGINE	√	√	√	√	√	1.Learned value reset(*)	1.READINESS TEST
JAPAN	I(アイ)	AT	√	√	√	√	√	1.Learned value reset	
JAPAN	I(アイ)	ABS	√	√	√	√	√		
JAPAN	I(アイ)	SRS		√	√	√	√		
JAPAN	I(アイ)	AC		√	√	√	√		
JAPAN	I(アイ)	METER	√	√	√	√	√	1.Service reminder(*)	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	I(アイ)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	CODING
JAPAN	I(アイ)	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	I(アイ)	LIN	√	√	√	√			
JAPAN	I(アイ)	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
JAPAN	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	
JAPAN	I-MIEV	SRS		√	√	√	√		
JAPAN	I-MIEV	AC		√	√	√	√		
JAPAN	I-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	
JAPAN	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	I-MIEV	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
JAPAN	I-MIEV	LIN	√	√	√	√			
JAPAN	I-MIEV	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
JAPAN	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	
JAPAN	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
JAPAN	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	
JAPAN	I-MIEV	MCU	√	√	√	√	√	1.Initial Phase Position Of Motor	



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	I-MIEV	CMU	√			√		1.Reset	
JAPAN	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	
JAPAN	LANCER	ENGINE	√	√	√	√	√		
JAPAN	LANCER	AT	√	√	√	√	√		
JAPAN	LANCER	ABS	√	√	√	√	√		
JAPAN	LANCER	IMMO	√	√	√	√	√		
JAPAN	LANCER	SRS	√	√	√	√	√		
JAPAN	LANCER	SWS	√	√	√	√	√		
JAPAN	LANCER	AC	√	√	√	√	√		
JAPAN	LANCER	AYC/ACD	√	√	√	√	√		
JAPAN	LANCER CARGO	ENGINE	√	√	√	√	√		
JAPAN	LANCER CARGO	ABS	√	√	√	√	√		
JAPAN	LANCER CARGO	SRS	√	√	√	√	√		
JAPAN	LANCER CARGO	SWS	√	√	√	√	√		
JAPAN	LANCER CARGO	AT	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	LANCER EVOLUTION	AT	√	√	√	√		1.Provisional DTCs 2.Teach-in	
JAPAN	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.Sensor calibration(*) 3.Valve pressure learning	
JAPAN	LANCER EVOLUTION	SRS	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	AC	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
JAPAN	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
JAPAN	LANCER EVOLUTION	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
JAPAN	LANCER EVOLUTION	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration(*)	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	LANCER WAGON	ABS	√	√	√	√	√		
JAPAN	LANCER WAGON	SRS	√	√	√	√	√		
JAPAN	LANCER WAGON	SWS	√	√	√	√	√		
JAPAN	LANCER WAGON	AC	√	√	√	√	√		
JAPAN	LANCER WAGON	IMMO	√	√	√	√	√		
JAPAN	LANCER WAGON	AYC/ACD	√	√	√	√	√		
JAPAN	MINICA	ENGINE	√	√	√	√	√		
JAPAN	MINICA	ABS	√	√	√	√	√		
JAPAN	MINICA	SRS	√	√	√	√	√		
JAPAN	MINICA	SWS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	ENGINE	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	ABS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	SRS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	SWS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	AT	√	√	√	√	√		
JAPAN	MINICAB-MIEV	ABS	√	√	√	√	√		
JAPAN	MINICAB-MIEV	SRS	√	√	√	√	√		
JAPAN	MINICAB-MIEV	4WS/Electric Power Steering	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	MINICAB-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	CODING
JAPAN	MINICAB-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	
JAPAN	MINICAB-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
JAPAN	MINICAB-MIEV	COMP&HTR	√	√	√	√	√	1.Temp.dial position adjust 2.Compressor drive history reset	
JAPAN	MINICAB-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	
JAPAN	MINICAB-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	
JAPAN	MINICAB-MIEV	CMU	√			√		Reset	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	MIRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	MIRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
JAPAN	MIRAGE	ABS	√	√	√	√			
JAPAN	MIRAGE	AC	√	√	√	√			
JAPAN	MIRAGE	SRS	√	√	√	√			
JAPAN	MIRAGE	METER	√	√	√	√			
JAPAN	MIRAGE	ETACS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	MIRAGE	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Keyless Reception Check 4.Key registration 5.Key registration (bar code number) 6.Engine Key Code registration 7.ENGINE KEY CODE registration&VIN WRITING 8.Comm. Test 9.KOS Key registration	
JAPAN	MIRAGE	4WS/Electric Power Steering	√	√	√	√			
JAPAN	MIRAGE	SAS	√	√	√	√			
JAPAN	MIRAGE	OSS	√	√	√	√			
JAPAN	OUTLANDER (CW#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (CW#)	AT	√	√	√	√	√	1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	
JAPAN	OUTLANDER (CW#)	ABS	√	√	√	√	√	1.Emission gas mode 2.All sensors calibration	
JAPAN	OUTLANDER (CW#)	SRS	√	√	√	√	√		
JAPAN	OUTLANDER (CW#)	AC	√	√	√	√	√		
JAPAN	OUTLANDER (CW#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	
JAPAN	OUTLANDER (CW#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
JAPAN	OUTLANDER (CW#)	SAS	√	√	√			SAS calibration	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (CW#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	OUTLANDER (CW#)	AUTO CRUISE	√	√	√	√			
JAPAN	OUTLANDER (CW#)	AND	√	√	√				
JAPAN	OUTLANDER (CW#)	LIN	√	√	√	√		Rain Sensor Adaptation	
JAPAN	OUTLANDER (CW#)	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	OUTLANDER (CW#)	AUDIO	√	√	√	√			
JAPAN	OUTLANDER (CW#)	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
JAPAN	OUTLANDER (CW#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (GF#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	OUTLANDER (GF#)	AT	√	√	√	√	√	1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	
JAPAN	OUTLANDER (GF#)	ABS	√	√	√	√	√	1.Emission gas mode 2.All sensors calibration	
JAPAN	OUTLANDER (GF#)	SRS	√	√	√	√	√		
JAPAN	OUTLANDER (GF#)	AC	√	√	√	√	√		
JAPAN	OUTLANDER (GF#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	OUTLANDER (GF#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (GF#)	SAS	√	√	√			SAS calibration	
JAPAN	OUTLANDER (GF#)	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	1.CODING
JAPAN	OUTLANDER (GF#)	AUTO CRUISE	√	√	√	√			
JAPAN	OUTLANDER (GF#)	AND	√	√	√				
JAPAN	OUTLANDER (GF#)	LIN	√	√	√	√		Rain Sensor Adaptation	
JAPAN	OUTLANDER (GF#)	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	OUTLANDER (GF#)	AUDIO	√	√	√	√			
JAPAN	OUTLANDER (GF#)	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
JAPAN	OUTLANDER (GF#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	OUTLANDER (GF#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
JAPAN	OUTLANDER (GF#)	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	OUTLANDER-PHEV	ABS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	AC	√	√	√	√			
JAPAN	OUTLANDER-PHEV	SRS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	OUTLANDER-PHEV	ETACS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	1.CODING
JAPAN	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			
JAPAN	OUTLANDER-PHEV	SAS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	LIN	√	√	√	√			
JAPAN	OUTLANDER-PHEV	BMU	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
JAPAN	OUTLANDER-PHEV	OSS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	AND	√	√	√	√			
JAPAN	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
JAPAN	OUTLANDER-PHEV	AUDIO	√	√	√	√			
JAPAN	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	OUTLANDER-PHEV	Compressor	√	√	√	√			
JAPAN	OUTLANDER-PHEV	F-MCU	√	√	√	√			
JAPAN	OUTLANDER-PHEV	GCU	√	√	√	√	√		
JAPAN	OUTLANDER-PHEV	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
JAPAN	OUTLANDER-PHEV	OBC	√	√	√	√			
JAPAN	OUTLANDER-PHEV	P LOCK	√	√	√	√			
JAPAN	OUTLANDER-PHEV	Power Gate	√	√	√	√			
JAPAN	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
JAPAN	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
JAPAN	OUTLANDER-PHEV	CMU	√			√			
JAPAN	PAJERO(V6#,V7#)	ENGINE	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	AT	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	ABS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO(V6#,V7#)	SRS	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	SWS	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	AC	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	IMMO	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	SS4II	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			
JAPAN	PAJERO(V6#,V7#)	HBB	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Write learned value(Changed ECU) 8.Learning value reset 9.OBD test results (Mode \$06) 10.In-use performance tracking(ENH) 11.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO(V8#,V9#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
JAPAN	PAJERO(V8#,V9#)	SRS	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	SWS	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	AC		√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	METER	√	√	√	√	√	Service reminder	
JAPAN	PAJERO(V8#,V9#)	ETACS	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration (key used) 3.ENG key code&Chassis No.registration	
JAPAN	PAJERO(V8#,V9#)	SS4II	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	HBB	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	DISPLAY	√	√	√				
JAPAN	PAJERO(V8#,V9#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
JAPAN	PAJERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
JAPAN	PAJERO(V8#,V9#)	LIN	√	√	√	√		Rain Sensor Adaptation	
JAPAN	PAJERO(V8#,V9#)	CAN/LIN/SWS converter	√	√	√	√		1.Customization 2.Customization information 3.Reset	
JAPAN	PAJERO MINI	ENGINE	√	√	√	√	√		
JAPAN	PAJERO MINI	AT	√	√	√	√	√		
JAPAN	PAJERO MINI	ABS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO MINI	SRS	√	√	√	√	√		
JAPAN	PAJERO MINI	SWS	√	√	√	√	√		
JAPAN	PAJERO IO	ENGINE	√	√	√	√	√		
JAPAN	PAJERO IO	AT	√	√	√	√	√		
JAPAN	PAJERO IO	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
JAPAN	PAJERO IO	SRS	√	√	√	√	√		
JAPAN	PAJERO IO	SWS	√	√	√	√	√		
JAPAN	PAJERO IO	AC	√	√	√	√	√		
JAPAN	RVR	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	RVR	AT	√	√	√	√		1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	RVR	ABS	√	√	√	√	√	1.Emission gas mode 2.All sensors calibration	
JAPAN	RVR	AC	√	√	√	√	√		
JAPAN	RVR	SRS	√	√	√	√	√		
JAPAN	RVR	AUTO CRUISE	√	√	√	√			
JAPAN	RVR	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	RVR	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
JAPAN	RVR	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	
JAPAN	RVR	SAS	√	√	√			SAS calibration	
JAPAN	RVR	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	RVR	AND	√	√	√				
JAPAN	RVR	LIN	√	√	√	√		Rain Sensor Adaptation	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	RVR	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	RVR	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
JAPAN	RVR	AS&G	√	√	√	√			
JAPAN	RVR	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
JAPAN	TOPPO	ENGINE	√	√	√	√	√		
JAPAN	TOPPO	AT	√	√	√	√	√		
JAPAN	TOPPO	ABS	√	√	√	√	√		
JAPAN	TOPPO	SRS		√	√	√	√		
JAPAN	TOPPO	SWS	√	√	√	√	√		
JAPAN	TRITON	ENGINE	√	√	√	√	√	1.Learned value reset	1.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	TRITON	AT	√	√	√	√	√	1.Learned value reset 2.Test(INVECS-2 control stopped)	
JAPAN	TRITON	ABS	√	√	√	√	√		
JAPAN	TRITON	SRS	√	√	√	√	√		
JAPAN	TRITON	AC	√	√	√	√	√		
JAPAN	TRITON	AUTO CRUISE	√	√	√	√			
JAPAN	TRITON	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	1.CODING
JAPAN	TRITON	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
JAPAN	TRITON	LIN	√	√	√	√			
JAPAN	TRITON	DISPLAY	√	√	√				

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ASX	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Ethanol forced learning mode 8.OBD test results (Mode \$06) 9.Learned value reset 10.In-use performance tracking(OBD) 11.In-use performance tracking(ENH) 12.Write learned value(changed ECU) 13.Timing chain maintenance	1.READINESS TEST 2.CODING
EUR	ASX	AT	√	√	√	√		1.Permit condition for AS&G 2.CVT oil degradation level 3.Electronic oil pump air bleeding 4.Emission gas mode 5.Control valve learning mode 6.Calibration value reset 7.Reset	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ASX	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	1.CODING
EUR	ASX	AC	√	√	√	√	√		
EUR	ASX	SRS	√	√	√	√	√		
EUR	ASX	AUTO CRUISE	√	√	√	√			
EUR	ASX	MULTI SELECT 4WD	√	√	√	√		Test	
EUR	ASX	AND	√	√	√	√	√		
EUR	ASX	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
EUR	ASX	LIN	√	√	√				
EUR	ASX	AUDIO	√	√	√	√			
EUR	ASX	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
EUR	ASX	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	1.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ASX	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Anti-theft warning device	1.CODING
EUR	ASX	4WS/Electric Power Steering	√	√	√	√	√		
EUR	ASX	IMMO	√	√	√	√			
EUR	ASX	CORNER SENSOR/BACK SENSOR	√	√	√	√			
EUR	ASX	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
EUR	ASX	AS&G	√	√	√	√			
EUR	ATTRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ATTRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
EUR	ATTRAGE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
EUR	ATTRAGE	AC	√	√	√	√			
EUR	ATTRAGE	SRS	√	√	√	√			
EUR	ATTRAGE	METER	√	√	√	√			
EUR	ATTRAGE	ETACS	√	√	√	√			
EUR	ATTRAGE	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ATTRAGE	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Keyless Reception Check 4.Key registration 5.Key registration (bar code number) 6.Engine Key Code registration 7.ENGINE KEY CODE registration&VIN WRITING 8.Comm. Test 9.KOS Key registration	
EUR	ATTRAGE	4WS/Electric Power Steering	√	√	√	√			
EUR	ATTRAGE	SAS	√	√	√	√			
EUR	ATTRAGE	LIN	√	√	√	√			
EUR	ATTRAGE	OSS	√	√	√	√			
EUR	COLT CZC	ENGINE	√	√	√	√	√	1.Learning	1.READINESS TEST 2.CODING
EUR	COLT CZC	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset 4.SAS calibration	1.CODING
EUR	COLT CZC	SRS	√	√	√	√	√	1.SRS ECU initialization	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	COLT CZC	AC	√	√	√	√	√		
EUR	COLT CZC	METER	√	√	√	√	√	1.Service reminder	1.CODING
EUR	COLT CZC	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Anti-theft warning device	
EUR	COLT CZC	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
EUR	COLT CZC	4WS/Electric Power Steering	√	√	√	√	√		1.CODING
EUR	COLT CZC	DISPLAY	√	√	√				
EUR	COLT CZC	RHT/TOPSTACK	√	√	√	√		1.Learning 2.Function test	1.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	COLT,COLT CZ3 / CZT	ENGINE	√	√	√	√	√	1.Learned value reset 2.test 3.learning 4.injector ID initialization 5.Injector ID writing(Exchanging Injector) 7.Injector ID Readout	1.READINESS TEST 2.CODING
EUR	COLT,COLT CZ3 / CZT	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	1.CODING
EUR	COLT,COLT CZ3 / CZT	SRS	√	√	√	√	√	1.SRS ECU initialization	
EUR	COLT,COLT CZ3 / CZT	AC	√	√	√	√	√		
EUR	COLT,COLT CZ3 / CZT	METER	√	√	√	√	√	1.Service reminder	1.CODING
EUR	COLT,COLT CZ3 / CZT	ETACS	√	√	√	√	√	1.Customization 2.Customization information	
EUR	COLT,COLT CZ3 / CZT	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
EUR	COLT,COLT CZ3 / CZT	4WS/Electric Power Steering	√	√	√	√	√		1.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	COLT, COLT CZ3 / CZT	DISPLAY	√	√	√	√	√		
EUR	COLT, COLT CZ3 / CZT	AT	√	√	√			1.Clutch 2.Gear	
EUR	GALANT	ENGINE	√	√	√	√	√	1.OBD test results (Mode \$06) 2.Learned value reset 3.In-use performance tracking(OBD) 4.In-use performance tracking(ENH)	1.READINESS TEST 2.CODING
EUR	GALANT	AT	√	√	√	√	√	1.Learned value reset 2.Test	
EUR	GALANT	ABS	√	√	√	√	√	1.Sensor calibration	
EUR	GALANT	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
EUR	GALANT	SWS	√	√	√	√	√		
EUR	GALANT	AC	√	√	√	√	√		
EUR	GALANT	METER	√	√	√	√	√		
EUR	GALANT	ETACS	√	√	√	√			



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	GRANDIS	AC	√	√	√	√	√		
EUR	GRANDIS	METER	√	√	√	√	√	1.Service reminder	
EUR	GRANDIS	ETACS	√	√	√	√			
EUR	GRANDIS	SAS	√	√	√			1.SAS calibration	
EUR	GRANDIS	AUTO CRUISE	√	√	√	√	√		1.CODING
EUR	GRANDIS	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
EUR	GRANDIS	DISPLAY	√	√	√	√	√		
EUR	GRANDIS	AT	√	√	√	√	√		
EUR	I	ENGINE	√	√	√	√	√	1.Learned value reset	1.READINESS TEST
EUR	I	AT	√	√	√	√	√	1.Learned value reset	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I	ABS	√	√	√	√	√		
EUR	I	SRS	√	√	√	√	√		
EUR	I	AC	√	√	√	√	√		
EUR	I	METER	√	√	√	√	√	1.Service reminder	
EUR	I	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	1.CODING
EUR	I	4WS/Electric Power Steering	√	√	√	√	√		
EUR	I	LIN	√	√	√	√			
EUR	I	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
EUR	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I-MIEV	SRS		√	√	√	√		
EUR	I-MIEV	AC		√	√	√	√		
EUR	I-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	
EUR	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
EUR	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
EUR	I-MIEV	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
EUR	I-MIEV	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password 5.Key Code agreement	1.CODING
EUR	I-MIEV	LIN	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I-MIEV	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
EUR	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	
EUR	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
EUR	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	
EUR	I-MIEV	MCU	√	√	√	√	√	1.Initial Phase Position Of Motor	
EUR	I-MIEV	CMU	√			√		1.Reset	





## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	L200(KA#,KB#)	ENGINE	√	√	√	√	√	1.Initialization(Supply pump exchange service)(*) 2.Test(Fuel system leak detection)(*) 3.Learning(Micro injection adaptation)(*) 4.Injector ID Writing(Exchanging Injector)(*) 5.Injector ID Readout(*)	1.CODING
EUR	L200(KA#,KB#)	ABS	√	√	√	√	√		
EUR	L200(KA#,KB#)	SRS	√	√	√	√	√		
EUR	L200(KA#,KB#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
EUR	L200(KA#,KB#)	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	L200(KA#,KB#)	LIN	√	√	√	√			
EUR	L200(KA#,KB#)	AT	√	√	√	√	√	1.Learned value reset 2.Test(INVECS-2 control stopped)	
EUR	L200(KA#,KB#)	AC	√	√	√	√	√		
EUR	L200(KA#,KB#)	SAS	√	√	√	√	√	1.SAS calibration	
EUR	L200(KA#,KB#)	DISPLAY	√	√	√				
EUR	L300	SRS	√	√	√	√	√		
EUR	LANCER(CS#,CT#)	ENGINE	√	√	√	√	√	1.test 2.learning 3.initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration	
EUR	LANCER(CS#,CT#)	ABS	√	√	√	√	√		
EUR	LANCER(CS#,CT#)	SRS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CS#,CT#)	SWS	√	√	√	√	√		
EUR	LANCER(CS#,CT#)	AC	√	√	√	√	√		
EUR	LANCER(CS#,CT#)	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	
EUR	LANCER(CS#,CT#)	AT	√	√	√	√	√		
EUR	LANCER(CS#,CT#)	AYC/ACD	√	√	√	√	√		1.READINESS TEST 2.CODING



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CY#)	AC	√	√	√	√	√		
EUR	LANCER(CY#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
EUR	LANCER(CY#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
EUR	LANCER(CY#)	SAS	√	√	√	√	√	1.SAS calibration(*)	
EUR	LANCER(CY#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	
EUR	LANCER(CY#)	4WS/Electric Power Steering	√	√	√	√	√		
EUR	LANCER(CY#)	MULTI SELECT 4WD	√	√	√	√		Test	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CY#)	AFS/ACL	√	√	√	√	√		
EUR	LANCER(CY#)	AND	√	√	√	√	√		
EUR	LANCER(CY#)	HFM	√	√	√	√	√		
EUR	LANCER(CY#)	AUDIO	√	√	√	√	√		
EUR	LANCER(CY#)	LIN	√	√	√	√	√		
EUR	LANCER(CY#)	AT	√	√	√	√	√	1.Learned value reset 2.Teach-In 3.test 4.Emission gas mode 5.CVT oil degradation level 6.Electronic oil pump air bleeding 7.Permit condition for AS&G	CODING
EUR	LANCER(CY#)	AUTO CRUISE	√	√	√	√			
EUR	LANCER(CY#)	AS&G	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.learning 2.Ethanol forced learning mode 3.Learned value reset 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Timing chain maintenance 8.initialization	1.READINESS TEST 2.CODING
EUR	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Emission gas mode 2.sensor calibration	
EUR	LANCER EVOLUTION	SRS	√	√	√	√	√		
EUR	LANCER EVOLUTION	AC	√	√	√	√	√		
EUR	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
EUR	LANCER EVOLUTION	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER EVOLUTION	SAS	√	√	√	√	√	1.SAS calibration(*)	
EUR	LANCER EVOLUTION	AFS/ACL	√	√	√	√	√		
EUR	LANCER EVOLUTION	Shift Lever	√	√	√	√	√		
EUR	LANCER EVOLUTION	HFM	√	√	√	√	√		
EUR	LANCER EVOLUTION	AT	√	√	√	√	√	1.Learned value reset 2.Teach-In 3.test	CODING
EUR	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
EUR	LANCER EVOLUTION	AUDIO	√	√	√	√	√		
EUR	LANCER EVOLUTION	AND	√	√	√	√	√		
EUR	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	
EUR	LANCER EVOLUTION	AYC/ACD	√	√	√	√	√	1.test 2.sensor calibration 3.Emission gas mode	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER SPORTBACK	AC	√	√	√	√	√		
EUR	LANCER SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
EUR	LANCER SPORTBACK	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
EUR	LANCER SPORTBACK	SAS	√	√	√	√	√	1.SAS calibration(*)	1.CODING
EUR	LANCER SPORTBACK	AFS/ACL	√	√	√	√	√		
EUR	LANCER SPORTBACK	4WS/Electric Power Steering	√	√	√	√	√		
EUR	LANCER SPORTBACK	AUDIO	√	√	√	√			
EUR	LANCER SPORTBACK	AND	√	√	√	√			
EUR	LANCER SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER SPORTBACK	AT	√	√	√	√	√	1.Learned value reset 2.Teach-In 3.test 4.Emission gas mode 5.CVT oil degradation level 6.Electronic oil pump air bleeding 7.Permit condition for AS&G	1.CODING
EUR	LANCER SPORTBACK	AYC/ACD	√	√	√	√	√	1.test 2.sensor calibration 3.Emission gas mode	
EUR	LANCER SPORTBACK	AUTO CRUISE	√	√	√	√			
EUR	LANCER SPORTBACK	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	1.CODING
EUR	LANCER SPORTBACK	HFM	√	√	√	√	√		
EUR	LANCER SPORTBACK	AS&G	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER WAGON	ENGINE	√	√	√	√	√		
EUR	LANCER WAGON	ABS	√	√	√	√	√		
EUR	LANCER WAGON	SRS	√	√	√	√	√		
EUR	LANCER WAGON	SWS	√	√	√	√	√		
EUR	LANCER WAGON	AC	√	√	√	√	√		
EUR	LANCER WAGON	IMMO	√	√	√	√	√		
EUR	LANCER WAGON	AT	√	√	√	√	√		
EUR	OUTLANDER(CU#)	ENGINE	√	√	√	√	√		
EUR	OUTLANDER(CU#)	ABS	√	√	√	√	√		
EUR	OUTLANDER(CU#)	SRS	√	√	√	√	√		
EUR	OUTLANDER(CU#)	SWS	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AC	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(CU#)	IMMO	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AND	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AT	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			
EUR	OUTLANDER(CW#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Ethanol forced learning mode 8.OBD test results (Mode \$06) 9.Learned value reset 10.In-use performance tracking(OBD) 11.In-use performance tracking(ENH) 12.Engine test 13.Timing chain maintenance	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(CW#)	AT	√	√	√	√	√	1.CVT oil degradation level (*) 2.Electronic oil pump air bleeding 3.Emission gas mode 4.Permit condition for AS&G	1.CODING
EUR	OUTLANDER(CW#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.Sensors calibration(*)	
EUR	OUTLANDER(CW#)	SRS	√	√	√	√	√		
EUR	OUTLANDER(CW#)	AC	√	√	√	√	√		
EUR	OUTLANDER(CW#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
EUR	OUTLANDER(CW#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(CW#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	
EUR	OUTLANDER(CW#)	AUTO CRUISE	√	√	√	√			
EUR	OUTLANDER(CW#)	AND	√	√	√	√	√		
EUR	OUTLANDER(CW#)	LIN	√	√	√	√			
EUR	OUTLANDER(CW#)	MULTI SELECT 4WD	√	√	√	√		Test	
EUR	OUTLANDER(CW#)	AUDIO	√	√	√	√	√		
EUR	OUTLANDER(CW#)	SAS	√	√	√	√	√	1.SAS calibration	
EUR	OUTLANDER(CW#)	HFM	√	√	√	√	√		
EUR	OUTLANDER(CW#)	AS&G	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(GF#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.Ethanol forced learning mode 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Test 8.Initialization 9.Injector ID Writing(Exchanging Injector) 10.Injector ID Readout 11.Write learned value(changed ECU) 12.DPF regeneration 13.Timing chain maintenance	
EUR	OUTLANDER(GF#)	AT	√	√	√	√	√	1.CVT oil degradation level (*) 2.Electronic oil pump air bleeding 3.Emission gas mode 4.Permit condition for AS&G	
EUR	OUTLANDER(GF#)	AC	√	√	√	√	√		
EUR	OUTLANDER(GF#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(GF#)	SAS	√	√	√			1.SAS calibration	
EUR	OUTLANDER(GF#)	4WS/Electric Power Steering	√	√	√	√	√		
EUR	OUTLANDER(GF#)	SRS	√	√	√	√			CODING
EUR	OUTLANDER(GF#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
EUR	OUTLANDER(GF#)	AND	√	√	√	√			
EUR	OUTLANDER(GF#)	AUDIO	√	√	√	√			
EUR	OUTLANDER(GF#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
EUR	OUTLANDER(GF#)	LIN	√	√	√				
EUR	OUTLANDER(GF#)	AWC	√	√	√	√			
EUR	OUTLANDER(GF#)	SWS	√	√	√	√	√		
EUR	OUTLANDER(GF#)	ETACS	√	√	√	√	√	1.Customization 2.Customization Information 3.Customization Reset 4.Security alarm 5.HS initial postion Clear 6.HS initial postion learing	CODING
EUR	OUTLANDER(GF#)	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(GF#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
EUR	OUTLANDER(GF#)	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
EUR	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
EUR	OUTLANDER-PHEV	ABS	√	√	√	√			
EUR	OUTLANDER-PHEV	AC	√	√	√	√			
EUR	OUTLANDER-PHEV	SRS	√	√	√	√			
EUR	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
EUR	OUTLANDER-PHEV	ETACS	√	√	√	√			
EUR	OUTLANDER-PHEV	IMMO	√	√	√	√			
EUR	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			
EUR	OUTLANDER-PHEV	SAS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER-PHEV	LIN	√	√	√	√			
EUR	OUTLANDER-PHEV	BMU	√	√	√	√			
EUR	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
EUR	OUTLANDER-PHEV	OSS	√	√	√	√			
EUR	OUTLANDER-PHEV	AND	√	√	√	√			
EUR	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
EUR	OUTLANDER-PHEV	AUDIO	√	√	√	√			
EUR	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
EUR	OUTLANDER-PHEV	Compressor	√	√	√	√			
EUR	OUTLANDER-PHEV	F-MCU	√	√	√	√			
EUR	OUTLANDER-PHEV	GCU	√	√	√	√	√		
EUR	OUTLANDER-PHEV	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
EUR	OUTLANDER-PHEV	OBC	√	√	√	√			
EUR	OUTLANDER-PHEV	P LOCK	√	√	√	√			
EUR	OUTLANDER-PHEV	Power Gate	√	√	√	√			
EUR	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
EUR	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
EUR	OUTLANDER-PHEV	CMU	√			√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO / MONTERO(V6#,V7#)	ENGINE	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6#,V7#)	ABS	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6#,V7#)	SRS	√	√	√	√			
EUR	PAJERO / MONTERO(V6#,V7#)	SWS	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6#,V7#)	IMMO	√	√	√	√		1.key registration(*) 2.Tester number display 3.Change Password(*)	
EUR	PAJERO / MONTERO(V6#,V7#)	SS4II	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6#,V7#)	HBB	√	√	√		√		
EUR	PAJERO / MONTERO(V6#,V7#)	AC	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6#,V7#)	AT	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			
EUR	PAJERO / MONTERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		1.READINESS TEST 2.CODING



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO / MONTERO(V8#,V9#)	AC	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	METER	√	√	√	√	√	1.Serve Reminder(*)	1.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	ETACS	√	√	√	√			1.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	IMMO	√	√	√	√		1.Change password(*) 2.Register Key 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
EUR	PAJERO / MONTERO(V8#,V9#)	SS4II	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	DISPLAY	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	ENGINE	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	ABS	√	√	√	√	√		





## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	ENGINE	√	√	√	√		1.Learned value reset 2.Learning 3.Test 4.Initialize(*) 5.Injector ID Writing(Exchanging Injector) 6.Reading Injector ID	1.READINESS TEST 2.CODING
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	ABS	√	√	√	√	√	1.Lateral G Sensor Calibratio	
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	SRS	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	AC	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions							
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others	
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	SAS	√	√	√	√			1.SAS Calibration(*)	
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	LIN	√	√	√					
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	IMMO	√	√	√	√			1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	1.CODING
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	AUTO CRUISE	√	√	√	√				
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	DISPLAY	√	√	√	√	√			1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	SPACE STAR	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
EUR	SPACE STAR	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
EUR	SPACE STAR	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
EUR	SPACE STAR	AC	√	√	√	√			
EUR	SPACE STAR	SRS	√	√	√	√			
EUR	SPACE STAR	METER	√	√	√	√			
EUR	SPACE STAR	ETACS	√	√	√	√			
EUR	SPACE STAR	IMMO	√	√	√	√			
EUR	SPACE STAR	4WS/Electric Power Steering	√	√	√	√			
EUR	SPACE STAR	SAS	√	√	√	√			
EUR	SPACE STAR	LIN	√	√	√	√			
EUR	SPACE STAR	OSS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ECLIPSE	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. CODING
USA	ECLIPSE	ABS	√	√	√	√	√	1.Sensor calibration 2.SAS calibration 3.Lateral G sensor calibration 4.M/C pressure calibration	
USA	ECLIPSE	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	ECLIPSE	SWS	√	√	√	√	√		
USA	ECLIPSE	AC	√	√	√	√	√		
USA	ECLIPSE	METER	√	√	√	√	√		
USA	ECLIPSE	ETACS	√	√	√				
USA	ECLIPSE	IMMO	√	√	√	√		1.Key registration (Use the key ) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	ECLIPSE	AUTO CRUISE	√	√	√	√			
USA	ECLIPSE	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ECLIPSE	TCL/STABILITY CONTROL	√	√	√	√	√	1.Key registration	
USA	ECLIPSE	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	ECLIPSE	SAS	√	√	√	√		1.SAS calibration	
USA	ECLIPSE SPYDER	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. READINESS TEST 2. CODING
USA	ECLIPSE SPYDER	ABS	√	√	√	√	√	1.Sensor calibration 2.SAS calibration 3.Lateral G sensor calibration 4.M/C pressure calibration	
USA	ECLIPSE SPYDER	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	ECLIPSE SPYDER	SWS	√	√	√	√	√		
USA	ECLIPSE SPYDER	AC	√	√	√	√	√		
USA	ECLIPSE SPYDER	METER	√	√	√	√	√		
USA	ECLIPSE SPYDER	ETACS	√	√	√				

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ECLIPSE SPYDER	IMMO	√	√	√	√	√	1.Key registration (Use the key ) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	ECLIPSE SPYDER	AUTO CRUISE	√	√	√	√			
USA	ECLIPSE SPYDER	RHT/TOPSTACK	√	√	√	√	√		
USA	ECLIPSE SPYDER	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	
USA	ECLIPSE SPYDER	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	ECLIPSE SPYDER	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	ECLIPSE SPYDER	SAS	√	√	√	√		1.SAS calibration	
USA	ENDEAVOR	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. READINESS TEST 2. CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ENDEAVOR	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	
USA	ENDEAVOR	ABS	√	√	√	√	√		
USA	ENDEAVOR	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	ENDEAVOR	SWS	√	√	√	√	√		
USA	ENDEAVOR	AC	√	√	√	√	√		
USA	ENDEAVOR	METER	√	√	√	√	√		
USA	ENDEAVOR	ETACS	√	√	√				
USA	ENDEAVOR	IMMO	√	√	√	√	√	1.Key registration (Use the key ) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	ENDEAVOR	AUTO CRUISE	√	√	√	√			
USA	ENDEAVOR	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	ENDEAVOR	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	ENDEAVOR	DISPLAY	√	√	√	√			
USA	ENDEAVOR	SAS	√	√	√	√		1.SAS calibration	



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	GALANT	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. READINESS TEST 2. CODING
USA	GALANT	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	
USA	GALANT	ABS	√	√	√	√	√	1.Sensor calibration 2.SAS calibration 3.Lateral G sensor calibration 4.M/C pressure calibration	
USA	GALANT	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	GALANT	SWS	√	√	√	√	√		
USA	GALANT	AC	√	√	√	√	√		
USA	GALANT	METER	√	√	√	√	√		
USA	GALANT	ETACS	√	√	√	√			
USA	GALANT	IMMO	√	√	√	√	√	1.Key registration (Use the key ) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	
USA	GALANT	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	GALANT	SAS	√	√	√	√		1.SAS calibration	
USA	GALANT	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	GALANT	DISPLAY	√	√	√	√	√		
USA	GALANT	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	LANCER(CS#,CT#)	ENGINE	√	√	√	√	√		
USA	LANCER(CS#,CT#)	ABS	√	√	√	√	√		
USA	LANCER(CS#,CT#)	SRS	√	√	√	√	√		
USA	LANCER(CS#,CT#)	SWS	√	√	√	√	√		
USA	LANCER(CS#,CT#)	AUTO CRUISE	√	√	√	√			
USA	LANCER(CS#,CT#)	AT	√	√	√	√	√		
USA	LANCER(CS#,CT#)	IMMO	√	√	√	√	√		
USA	LANCER(CS#,CT#)	AYC/ACD	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER(CY#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	LANCER(CY#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Frozen Keys	
USA	LANCER(CY#)	SRS	√	√	√	√	√		
USA	LANCER(CY#)	AC	√	√	√	√	√		
USA	LANCER(CY#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
USA	LANCER(CY#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER(CY#)	IMMO	√	√	√	√	√	1.Key registration (Use the key ) 2.Key registration(The number of the bar code) 3.Engine Key Code registration 4.Short of key ID Registration (*) 5.ENGINE KEY CODE registration&VIN WRITING 6.Change Password	1.CODING
USA	LANCER(CY#)	HFM	√	√	√	√	√		
USA	LANCER(CY#)	AUDIO	√	√	√	√	√		
USA	LANCER(CY#)	4WS/Electric Power Steering	√	√	√	√	√		
USA	LANCER(CY#)	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	LANCER(CY#)	AUTO CRUISE	√	√	√	√			
USA	LANCER(CY#)	Shift Lever	√	√	√	√	√		
USA	LANCER(CY#)	AND	√	√	√	√	√		
USA	LANCER(CY#)	SATELLITE RADIO	√	√	√	√	√		
USA	LANCER(CY#)	SAS	√	√	√			1.SAS calibration(*)	
USA	LANCER(CY#)	LIN	√	√	√	√		Rain sensor adaptation	
USA	LANCER(CY#)	AYC/ACD	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Test	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER(CY#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level (*) 3.Teach-in 4.Emission gas mode	1.CODING
USA	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	LANCER EVOLUTION	AT	√	√	√	√	√	1.Teach-in	1.CODING
USA	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Valve pressure learning 2.Emission gas mode(*) 3.Sensor calibration(*)	
USA	LANCER EVOLUTION	SRS	√	√	√	√	√		
USA	LANCER EVOLUTION	AC	√	√	√	√	√		
USA	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER EVOLUTION	AYC/ACD	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Test	
USA	LANCER EVOLUTION	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
USA	LANCER EVOLUTION	SAS	√	√	√			1.SAS calibration(*)	1.CODING
USA	LANCER EVOLUTION	TPMS	√	√	√	√		1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*)	
USA	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.ENGINE KEY CODE registration&VIN WRITING 2.Security application file generation 3.Comm. test 4.Steering lock unit registration 5.Engine Key Code registration 6.Key & KOS key registration 7.Change password	1.CODING
USA	LANCER EVOLUTION	HFM	√	√	√	√	√		
USA	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
USA	LANCER EVOLUTION	AND	√	√	√	√	√		
USA	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER EVOLUTION	AUDIO	√	√	√	√	√		
USA	LANCER EVOLUTION	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	LANCER EVOLUTION	SATELLITE RADIO	√	√	√	√	√		
USA	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		
USA	LANCER SPORTBACK(CS#)	ENGINE	√	√	√	√	√		
USA	LANCER SPORTBACK(CS#)	AT	√	√	√	√	√		
USA	LANCER SPORTBACK(CS#)	ABS	√	√	√	√	√		
USA	LANCER SPORTBACK(CS#)	SRS	√	√	√	√			
USA	LANCER SPORTBACK(CS#)	SWS	√	√	√	√	√		
USA	LANCER SPORTBACK(CX#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER SPORTBACK(CX#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level (*) 3.Teach-in 4.Emission gas mode	1.CODING
USA	LANCER SPORTBACK(CX#)	ABS	√	√	√	√	√	1.Forzen Key 2.Emission gas mode(*) 3.Sensor calibration(*)	
USA	LANCER SPORTBACK(CX#)	SRS	√	√	√	√	√		
USA	LANCER SPORTBACK(CX#)	AC	√	√	√	√	√		
USA	LANCER SPORTBACK(CX#)	METER	√	√	√	√	√	1 Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
USA	LANCER SPORTBACK(CX#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
USA	LANCER SPORTBACK(CX#)	SAS	√	√	√			1.SAS calibration(*)	





## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER SPORTBACK(CX#)	SHIFT LEVER	√	√	√	√	√		
USA	MIRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
USA	MIRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
USA	MIRAGE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
USA	MIRAGE	AC	√	√	√	√			
USA	MIRAGE	SRS	√	√	√	√			
USA	MIRAGE	METER	√	√	√	√			
USA	MIRAGE	ETACS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	MIRAGE	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	
USA	MIRAGE	IMMO	√	√	√	√			
USA	MIRAGE	4WS/Electric Power Steering	√	√	√	√			
USA	MIRAGE	SAS	√	√	√	√			
USA	MIRAGE	OSS	√	√	√	√			
USA	MIRAGE	OCM	√	√	√	√			
USA	MONTERO	ENGINE	√	√	√	√	√		
USA	MONTERO	AT	√	√	√	√	√		
USA	MONTERO	ABS	√	√	√	√	√		
USA	MONTERO	SRS	√	√	√	√	√		
USA	MONTERO	SWS	√	√	√	√	√		
USA	MONTERO	IMMO	√	√	√	√	√		
USA	MONTERO	AUTO CRUISE	√	√	√	√			
USA	MONTERO	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	MONTERO	TCL/STABILITY CONTROL	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	MONTERO	SS4II	√	√	√	√	√		
USA	MONTERO	AC	√	√	√	√	√		
USA	MONTERO	HBB	√	√	√	√	√		
USA	OUTLANDER(CU#)	ENGINE	√	√	√	√	√		
USA	OUTLANDER(CU#)	ABS	√	√	√	√	√		
USA	OUTLANDER(CU#)	SRS	√	√	√	√	√		
USA	OUTLANDER(CU#)	SWS	√	√	√	√	√		
USA	OUTLANDER(CU#)	IMMO	√	√	√	√	√		
USA	OUTLANDER(CU#)	AND	√	√	√	√	√		
USA	OUTLANDER(CU#)	AT	√	√	√	√	√		
USA	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			
USA	OUTLANDER(CU#)	AC	√	√	√	√	√		
USA	OUTLANDER(CW#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	OUTLANDER(CW#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level (*) 3.Permit condition for AS&G 4.Emission gas mode	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(CW#)	ABS	√	√	√	√	√	1.Forzen key 2.Emission gas mode(*) 3.All sensors calibration(*)	
USA	OUTLANDER(CW#)	SRS	√	√	√	√			
USA	OUTLANDER(CW#)	AC	√	√	√	√	√		
USA	OUTLANDER(CW#)	METER	√	√	√	√	√	1.test 2.Head lamp Auto leveling Diag mode(*) 3.Service reminder(*)	
USA	OUTLANDER(CW#)	ETACS	√	√	√	√	√	1.Alarm record (optional)(*) 2.Customization(*) 3.Customization Information(*) 4.Customization Reset(*)	
USA	OUTLANDER(CW#)	SAS	√	√	√			1.SAS calibration(*)	
USA	OUTLANDER(CW#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*)	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(CW#)	IMMO	√	√	√	√	√	1.ENGINE KEY CODE registration&VIN WRITING 2.Steering lock unit registration 3.Key registration (bar code number)(*) 4.Key&KOS (Keyless Operation System) 5.key registration (*) 6.Engine Key Code registration 7.Security application file generation 8.Comm. Test 9.Change Password	
USA	OUTLANDER(CW#)	AUTO CRUISE	√	√	√	√			
USA	OUTLANDER(CW#)	AND	√	√	√	√	√		
USA	OUTLANDER(CW#)	LIN	√	√	√	√		Rain sensor adaptation	
USA	OUTLANDER(CW#)	AUDIO	√	√	√	√	√		
USA	OUTLANDER(CW#)	HFM	√	√	√	√	√		
USA	OUTLANDER(CW#)	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	OUTLANDER(CW#)	SATELLITE RADIO	√	√	√	√			
USA	OUTLANDER(CW#)	MULTI SELECT 4WD	√	√	√	√		Test	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(GF#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	OUTLANDER(GF#)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Electronic oil pump air bleeding 4.Permit condition for AS&G	
USA	OUTLANDER(GF#)	ABS	√	√	√	√			
USA	OUTLANDER(GF#)	AC	√	√	√	√			
USA	OUTLANDER(GF#)	SRS	√	√	√	√			
USA	OUTLANDER(GF#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
USA	OUTLANDER(GF#)	ETACS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(GF#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	
USA	OUTLANDER(GF#)	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING
USA	OUTLANDER(GF#)	AUTO CRUISE	√	√	√	√			
USA	OUTLANDER(GF#)	4WS/Electric Power Steering	√	√	√	√			
USA	OUTLANDER(GF#)	SAS	√	√	√	√			
USA	OUTLANDER(GF#)	LIN	√	√	√	√			
USA	OUTLANDER(GF#)	AWC	√	√	√	√			
USA	OUTLANDER(GF#)	OSS	√	√	√	√			
USA	OUTLANDER(GF#)	AND	√	√	√	√			
USA	OUTLANDER(GF#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
USA	OUTLANDER(GF#)	AUDIO	√	√	√	√			
USA	OUTLANDER(GF#)	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
USA	OUTLANDER(GF#)	Power Gate	√	√	√	√			





## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER SPORT/RVR	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
USA	OUTLANDER SPORT/RVR	METER	√	√	√	√	√	1 Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
USA	OUTLANDER SPORT/RVR	SAS	√	√	√			1.SAS Calibration	
USA	OUTLANDER SPORT/RVR	MULTI SELECT 4WD	√	√	√	√		Test	
USA	OUTLANDER SPORT/RVR	AND	√	√	√	√	√		
USA	OUTLANDER SPORT/RVR	LIN	√	√	√	√		Rain sensor adaptation	
USA	OUTLANDER SPORT/RVR	AUDIO	√	√	√	√	√		
USA	OUTLANDER SPORT/RVR	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	OUTLANDER SPORT/RVR	SATELLITE RADIO	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER SPORT/RVR	IMMO	√	√	√	√	√	1.Change Password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine Key Code registration 6.ENGINE KEY CODE registration&VIN WRITING 7.Key&KOS 8.Steering lock unit registration 9.Comm. Test	CODING
USA	I-MIEV	AC	√	√	√	√	√		
USA	I-MIEV	ABS	√	√	√	√	√	1.Emission gas mode(*)	
USA	I-MIEV	SRS	√	√	√	√			
USA	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
USA	I-MIEV	ETACS	√	√	√	√	√	1.Key&KOS (Keyless Operation System) key registration (*) 2.Customization(*) 3.Customization Information(*) 4.Customization Reset(*) 5.Keyless receiving inspection	CODING
USA	I-MIEV	METER	√	√	√	√	√	1.Serve Reminder(*) 2.Test	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	I-MIEV	SAS	√	√	√			1.SAS calibration(*)	
USA	I-MIEV	LIN	√	√	√	√			
USA	I-MIEV	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration(bar code number)(*) 4.Key code consistency validation 5.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	I-MIEV	OCM	√	√	√	√	√		
USA	I-MIEV	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check	
USA	I-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	
AUSTRALIA		380 ENGINE	√	√	√	√	√	1.Learned Value Reset	1.READINESS TEST 2.CODING
AUSTRALIA		380 ABS	√	√	√	√	√		
AUSTRALIA		380 SRS	√	√	√	√	√		
AUSTRALIA		380 SWS	√	√	√	√	√		
AUSTRALIA		380 AC	√	√	√	√	√		
AUSTRALIA		380 METER	√	√	√	√	√		
AUSTRALIA		380 ETACS	√	√	√				

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	380	IMMO	√	√	√	√		1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*) 4.Key registration (key used)	1.CODING
AUSTRALIA	380	AUTO CRUISE	√	√	√	√			
AUSTRALIA	380	TCL/STABILITY CONTROL	√	√	√	√	√		
AUSTRALIA	380	DISPLAY	√	√	√		√		
AUSTRALIA	380	AT	√	√	√	√	√	1.Learned Value Reset 2.Test	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	ASX	SRS	√	√	√	√	√		
AUSTRALIA	ASX	AUTO CRUISE	√	√	√	√			
AUSTRALIA	ASX	4WS/ELECTRIC POWER STEERING	√	√	√	√	√		
AUSTRALIA	ASX	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
AUSTRALIA	ASX	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	
AUSTRALIA	ASX	SAS	√	√	√			SAS calibration	
AUSTRALIA	ASX	MULTI SELECT 4WD	√	√	√	√		Test	
AUSTRALIA	ASX	AND	√	√	√				
AUSTRALIA	ASX	AUDIO	√	√	√	√			
AUSTRALIA	ASX	LIN	√	√	√	√		Rain sensor adaptation	





## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	CHALLENGER(K9#)	IMMO	√	√	√	√	√		
AUSTRALIA	CHALLENGER(K9#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	CHALLENGER(K9#)	AT	√	√	√	√	√		
AUSTRALIA	CHALLENGER (KG#,KH#)	ENGINE	√	√	√	√	√	1.Learning 2.Test 3.Initialize(*) 4.Injector ID Writing(Exchanging Injector) 5.Reading Injector ID	1.CODING
AUSTRALIA	CHALLENGER (KG#,KH#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
AUSTRALIA	CHALLENGER (KG#,KH#)	ABS	√	√	√	√	√	1.Lateral G Sensor Calibration	
AUSTRALIA	CHALLENGER (KG#,KH#)	AC	√	√	√	√	√		
AUSTRALIA	CHALLENGER (KG#,KH#)	SRS		√	√	√	√		
AUSTRALIA	CHALLENGER (KG#,KH#)	ETACS	√	√	√	√		1.Customization 2.Customization Information 3.Customization Reset 4.Short of key ID Registration 5.Short or Key Access Check	1.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	CHALLENGER (KG#,KH#)	IMMO	√	√	√	√		1.Key Registration(using key) 2.Key Registration(bar code number) 3.Change password 4.ENGINE KEY CODE registration&VIN WRITING	1.CODING
AUSTRALIA	CHALLENGER (KG#,KH#)	LIN	√	√	√	√			
AUSTRALIA	CHALLENGER (KG#,KH#)	SAS	√	√	√			SAS Calibration	
AUSTRALIA	CHALLENGER (KG#,KH#)	DISPLAY	√	√	√				
AUSTRALIA	COLT	ENGINE	√	√	√	√	√		
AUSTRALIA	COLT	AT	√	√	√	√	√		
AUSTRALIA	COLT	ABS	√	√	√	√	√	1.Emissions Gas Mode(*) 2.SAS Calibration(*) 3.Yaw rate sensor type reset	
AUSTRALIA	COLT	SRS	√	√	√	√	√		
AUSTRALIA	COLT	SWS	√	√	√	√	√		
AUSTRALIA	COLT	AC	√	√	√	√	√		
AUSTRALIA	COLT	METER	√	√	√	√	√		
AUSTRALIA	COLT	ETACS	√	√	√	√	√		
AUSTRALIA	COLT	IMMO	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	COLT	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	COLT CABRIOLET	ENGINE	√	√	√	√	√	1.Learning	1.READINESS TEST 2.CODING
AUSTRALIA	COLT CABRIOLET	ABS	√	√	√	√	√	1.Emissions Gas Mode 2.SAS Calibration 3.Yaw rate sensor type reset	1.CODING
AUSTRALIA	COLT CABRIOLET	SRS	√	√	√	√	√	SRS ECU Initialize	
AUSTRALIA	COLT CABRIOLET	AC	√	√	√	√	√		
AUSTRALIA	COLT CABRIOLET	METER	√	√	√	√	√	Service reminder	1.CODING
AUSTRALIA	COLT CABRIOLET	ETACS	√	√	√	√	√	1.Customization 2.Customization Information	1.CODING
AUSTRALIA	COLT CABRIOLET	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
AUSTRALIA	COLT CABRIOLET	4WS/Electric Power Steering	√	√	√	√	√		1.CODING
AUSTRALIA	COLT CABRIOLET	DISPLAY	√	√	√	√	√		
AUSTRALIA	COLT CABRIOLET	RHT/TOPSTACK		√	√	√	√	1.Studying 2.Function Test	1.CODING
AUSTRALIA	EXPRESS(PB#)	ENGINE	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	ABS	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	SRS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	EXPRESS(PB#)	ETACS	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	IMMO	√	√	√	√	√		
AUSTRALIA	EXPRESS / STAR WAGON(P0#,P1#)	ENGINE	√	√	√	√	√		
AUSTRALIA	GRANDIS	ENGINE	√	√	√	√	√		
AUSTRALIA	GRANDIS	AT	√	√	√	√	√		
AUSTRALIA	GRANDIS	ABS	√	√	√	√	√		
AUSTRALIA	GRANDIS	SRS	√	√	√	√	√		
AUSTRALIA	GRANDIS	SWS	√	√	√	√	√		
AUSTRALIA	GRANDIS	AC	√	√	√	√	√		
AUSTRALIA	GRANDIS	METER	√	√	√	√	√		
AUSTRALIA	GRANDIS	ETACS	√	√	√	√	√		
AUSTRALIA	GRANDIS	IMMO	√	√	√	√	√		
AUSTRALIA	GRANDIS	AUTO CRUISE	√	√	√	√			
AUSTRALIA	GRANDIS	AND	√	√	√	√	√		
AUSTRALIA	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	
AUSTRALIA	I-MIEV	AC		√	√	√	√		
AUSTRALIA	I-MIEV	SRS		√	√	√	√		
AUSTRALIA	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization Information 3.Customization Reset 4.Short of key ID Registration 5.Short or Key Access Check	1.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	I-MIEV	METER	√	√	√	√	√	1.Test 2.Service reminder	
AUSTRALIA	I-MIEV	SAS	√	√	√			SAS Calibration	
AUSTRALIA	I-MIEV	LIN	√	√	√	√			
AUSTRALIA	I-MIEV	Keyless Operation	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
AUSTRALIA	I-MIEV	IMMO	√	√	√	√		1.key Registration key(using key) 2.Key Registration(bar code number) 3.Change password 4.ENGINE KEY CODE registration&VIN WRITING 5.Key Code agreement	1.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
AUSTRALIA	I-MIEV	COMP&HTR	√	√	√	√	√	Compressor drive history reset	
AUSTRALIA	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	
AUSTRALIA	I-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	
AUSTRALIA	I-MIEV	CMU	√			√		reset	
AUSTRALIA	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	LANCER	AT	√	√	√	√	√	1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-in 5.Emission gas mode	1.CODING
AUSTRALIA	LANCER	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
AUSTRALIA	LANCER	SRS	√	√	√	√	√		
AUSTRALIA	LANCER	AC	√	√	√	√	√		
AUSTRALIA	LANCER	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	LANCER	AYC/ACD	√	√	√	√		1.Sensor calibration 2.Air bleeding 3.Test	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
AUSTRALIA	LANCER	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
AUSTRALIA	LANCER	SAS	√	√	√			1.SAS calibration(*)	
AUSTRALIA	LANCER	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	LANCER	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	LANCER	AUDIO	√	√	√	√			



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER	AND	√	√	√				
AUSTRALIA	LANCER	HFM	√	√	√	√	√		
AUSTRALIA	LANCER	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
AUSTRALIA	LANCER	SHIFT LEVER	√	√	√	√	√		
AUSTRALIA	LANCER	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	LANCER EVOLUTION	AT	√	√	√	√		1.Provisional DTCs 2.Teach-in	
AUSTRALIA	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Valve pressure learning	
AUSTRALIA	LANCER EVOLUTION	SRS	√	√	√	√	√		
AUSTRALIA	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER EVOLUTION	AC	√	√	√	√	√		
AUSTRALIA	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
AUSTRALIA	LANCER EVOLUTION	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
AUSTRALIA	LANCER EVOLUTION	SAS	√	√	√			1.SAS calibration	
AUSTRALIA	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER EVOLUTION	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
AUSTRALIA	LANCER EVOLUTION	AYC/ACD	√	√	√	√		1.Sensor Calibration 2.Air bleeding 3.Test	
AUSTRALIA	LANCER EVOLUTION	AND	√	√	√				
AUSTRALIA	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	LANCER EVOLUTION	AUDIO	√	√	√	√			
AUSTRALIA	LANCER EVOLUTION	HFM	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	ENGINE	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	ABS	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	SRS	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	SWS	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	IMMO	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER SEDAN	AT	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	AC	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	AYC/ACD	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER SPORTBACK	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	LANCER SPORTBACK	AT	√	√	√	√		1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-in 5.Emission gas mode	1.CODING
AUSTRALIA	LANCER SPORTBACK	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
AUSTRALIA	LANCER SPORTBACK	SRS	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	SHIFT LEVER	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	AC	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER SPORTBACK	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
AUSTRALIA	LANCER SPORTBACK	SAS	√	√	√			1.SAS calibration	
AUSTRALIA	LANCER SPORTBACK	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	LANCER SPORTBACK	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER SPORTBACK	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER SPORTBACK	AYC/ACD	√	√	√	√	√	1.Sensor Calibration 2.Air bleeding 3.Test	
AUSTRALIA	LANCER SPORTBACK	AND	√	√	√				
AUSTRALIA	LANCER SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	LANCER SPORTBACK	AUDIO	√	√	√	√			
AUSTRALIA	LANCER SPORTBACK	HFM	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	LANCER WAGON	ENGINE	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	ABS	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	SRS	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	SWS	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	AC	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	IMMO	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER WAGON	AT	√	√	√	√	√		
AUSTRALIA	MIRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	MIRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
AUSTRALIA	MIRAGE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
AUSTRALIA	MIRAGE	AC	√	√	√	√			
AUSTRALIA	MIRAGE	SRS	√	√	√	√			
AUSTRALIA	MIRAGE	METER	√	√	√	√			
AUSTRALIA	MIRAGE	ETACS	√	√	√	√			
AUSTRALIA	MIRAGE	IMMO	√	√	√	√			
AUSTRALIA	MIRAGE	4WS/Electric Power Steering	√	√	√	√			
AUSTRALIA	MIRAGE	SAS	√	√	√	√			
AUSTRALIA	MIRAGE	LIN	√	√	√	√			
AUSTRALIA	MIRAGE	OSS	√	√	√	√			
AUSTRALIA	OUTLANDER(CU#)	ENGINE	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	AT	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	ABS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	SRS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	SWS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	AC	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	IMMO	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(CW#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	OUTLANDER(CW#)	AT	√	√	√	√	√	1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-in 5.Emission gas mode	CODING
AUSTRALIA	OUTLANDER(CW#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
AUSTRALIA	OUTLANDER(CW#)	SRS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CW#)	AC	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CW#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(CW#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
AUSTRALIA	OUTLANDER(CW#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	OUTLANDER(CW#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	OUTLANDER(CW#)	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
AUSTRALIA	OUTLANDER(CW#)	AND	√	√	√				
AUSTRALIA	OUTLANDER(CW#)	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	OUTLANDER(CW#)	MULTI SELECT 4WD	√	√	√	√		Test	
AUSTRALIA	OUTLANDER(CW#)	AUDIO	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(CW#)	SAS	√	√	√			1.SAS calibration	
AUSTRALIA	OUTLANDER(CW#)	HFM	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CW#)	AWC	√	√	√	√		1.Reset 2.Test	
AUSTRALIA	OUTLANDER(CW#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.In-use performance tracking(OBD) 7.Write learned value(changed ECU) 8.DPF regeneration 9.In-use performance tracking(ENH) 10.Timing chain maintenance 11.Learned value reset 12.Ethanol forced learning mode	1.CODING 2.READINESS TEST
AUSTRALIA	OUTLANDER(GF#)	AT	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(GF#)	ABS	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	AC	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	SRS	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
AUSTRALIA	OUTLANDER(GF#)	ETACS	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	IMMO	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	4WS/Electric Power Steering	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	SAS	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	LIN	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	AWC	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	OSS	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	AND	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
AUSTRALIA	OUTLANDER(GF#)	AUDIO	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	OUTLANDER(GF#)	Power Gate	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	OUTLANDER-PHEV	ABS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	AC	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	SRS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
AUSTRALIA	OUTLANDER-PHEV	ETACS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING
AUSTRALIA	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	SAS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	LIN	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	BMU	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	OSS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	AND	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
AUSTRALIA	OUTLANDER-PHEV	AUDIO	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	Compressor	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	F-MCU	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	GCU	√	√	√	√	√		
AUSTRALIA	OUTLANDER-PHEV	OBC	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	P LOCK	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	Power Gate	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
AUSTRALIA	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
AUSTRALIA	OUTLANDER-PHEV	CMU	√	√	√	√			
AUSTRALIA	PAJERO(V7#)	ENGINE	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	ABS	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	SRS	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	SWS	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	IMMO	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	PAJERO(V7#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	PAJERO(V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	SS4II	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	AT	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	AC	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Write learned value(Changed ECU) 8.Learning value reset 9.OBD test results (Mode \$06) 10.In-use performance tracking(ENH) 11.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
AUSTRALIA	PAJERO(V8#,V9#)	AT	√	√	√	√	√	1.Learn value reset(*) 2.Test(INVECS-2 control stopped)(*)	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	PAJERO(V8#,V9#)	ABS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	SRS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	SWS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	AC		√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	METER	√	√	√	√	√	1.Service reminder(*)	
AUSTRALIA	PAJERO(V8#,V9#)	ETACS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	IMMO	√	√	√	√		1.Change password(*) 2.Key registration (using key) 3.Key&KOS (Keyless Operation System) key registration (*)	
AUSTRALIA	PAJERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	PAJERO(V8#,V9#)	SS4II	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	DISPLAY	√	√	√				
AUSTRALIA	PAJERO(V8#,V9#)	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	PAJERO(V8#,V9#)	CAN/LIN/SWS converter	√	√	√	√		1.Customization 2.Customization information 3.Reset	
AUSTRALIA	TRITON(K6#,K7#)	ENGINE	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	IMMO	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	ETACS	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	ABS	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	SRS	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	AT	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	TRITON(KA#,KB#)	ENGINE	√	√	√	√	√	1.Learn valued Reset(*) 2.Test 3.Initialize(*) 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout	1.CODING
AUSTRALIA	TRITON(KA#,KB#)	ABS	√	√	√	√	√		
AUSTRALIA	TRITON(KA#,KB#)	SRS		√	√	√	√		
AUSTRALIA	TRITON(KA#,KB#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
AUSTRALIA	TRITON(KA#,KB#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key registration (using key) 4.ENGINE KEY CODE registration&VIN WRITING	1.CODING
AUSTRALIA	TRITON(KA#,KB#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
AUSTRALIA	TRITON(KA#,KB#)	AC	√	√	√	√	√		
AUSTRALIA	TRITON(KA#,KB#)	LIN	√	√	√	√			
AUSTRALIA	TRITON(KA#,KB#)	DISPLAY	√	√	√				



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	TRITON(KA#,KB#)	SAS	√	√	√			SAS Calibration	
GENERAL	380	ENGINE	√	√	√	√	√	1.Learn valued Reset(*)	1.READINESS TEST 2.CODING
GENERAL	380	ABS	√	√	√	√	√		
GENERAL	380	SRS	√	√	√	√	√		
GENERAL	380	SWS	√	√	√	√	√		
GENERAL	380	AC	√	√	√	√	√		
GENERAL	380	METER	√	√	√	√	√		
GENERAL	380	ETACS	√	√	√				
GENERAL	380	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
GENERAL	380	AUTO CRUISE	√	√	√	√			
GENERAL	380	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	380	DISPLAY	√	√	√	√	√		
GENERAL	380	AT	√	√	√	√	√	1.Test 2.Learned Value Reset(*)	
GENERAL	ADVENTURE	ENGINE	√	√	√	√	√		
GENERAL	ADVENTURE	AT	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode 8.Test 9.initialization 10.Injector ID Writing(Exchanging Injector) 11.Injector ID Readout 12.DPF regeneration 13.Write learned value(changed ECU)	1.READINESS TEST 2.CODING
GENERAL	ASX / OUTLANDER SPORT / RVR	AT	√	√	√	√		1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Emission gas mode 4.Control valve learning mode 5.Calibration value reset 6.Reset	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	ABS	√	√	√	√	√	1.Sensor calibration 2.Emission gas mode	
GENERAL	ASX / OUTLANDER SPORT / RVR	AC	√	√	√	√	√		
GENERAL	ASX / OUTLANDER SPORT / RVR	SRS	√	√	√	√	√		
GENERAL	ASX / OUTLANDER SPORT / RVR	AUTO CRUISE	√	√	√	√			
GENERAL	ASX / OUTLANDER SPORT / RVR	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	ASX / OUTLANDER SPORT / RVR	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.4.Alarm record (optional)(*)	
GENERAL	ASX / OUTLANDER SPORT / RVR	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
GENERAL	ASX / OUTLANDER SPORT / RVR	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	ASX / OUTLANDER SPORT / RVR	MULTI SELECT 4WD	√	√	√	√		Test	
GENERAL	ASX / OUTLANDER SPORT / RVR	AND	√	√	√				

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	ASX / OUTLANDER SPORT / RVR	AUDIO	√	√	√	√			
GENERAL	ASX / OUTLANDER SPORT / RVR	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	1.CODING
GENERAL	ASX / OUTLANDER SPORT / RVR	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
GENERAL	ASX / OUTLANDER SPORT / RVR	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
GENERAL	ASX / OUTLANDER SPORT / RVR	CORNER SENSOR/BACK SENSOR	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ATTRAGE/MIRAGE G4	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	ATTRAGE/MIRAGE G4	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
GENERAL	ATTRAGE/MIRAGE G4	ABS	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	AC	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	SRS	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	METER	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	ETACS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ATTRAGE/MIRAGE G4	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Keyless Reception Check 4.Key registration 5.Key registration (bar code number) 6.Engine Key Code registration 7.ENGINE KEY CODE registration&VIN WRITING 8.Comm. Test 9.KOS Key registration	
GENERAL	ATTRAGE/MIRAGE G4	4WS/Electric Power Steering	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	OSS	√	√	√	√			
GENERAL	CHARIOT	ENGINE	√	√	√	√	√		
GENERAL	CHARIOT	AT	√	√	√	√	√		
GENERAL	CHARIOT	ABS	√	√	√	√	√		
GENERAL	CHARIOT	SWS	√	√	√	√	√		
GENERAL	CHARIOT	AC	√	√	√	√	√		
GENERAL	CHARIOT	IMMO	√	√	√	√	√		
GENERAL	CHARIOT	SRS	√	√	√	√	√		
GENERAL	COLT CABRIOLET	ENGINE	√	√	√	√	√	1.Learning	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	COLT CABRIOLET	ABS	√	√	√	√	√	1.YAW rate Sensor type reset 2.Emissions Gas Mode(*) 3.SAS Calibration(*)	1.CODING
GENERAL	COLT CABRIOLET	SRS	√	√	√	√	√	1.SRS ECU Initialize	
GENERAL	COLT CABRIOLET	AC	√	√	√	√	√		
GENERAL	COLT CABRIOLET	METER	√	√	√	√	√	1.Service reminder	
GENERAL	COLT CABRIOLET	ETACS	√	√	√	√	√	1.Customization 2.Customization information	1.CODING
GENERAL	COLT CABRIOLET	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
GENERAL	COLT CABRIOLET	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	COLT CABRIOLET	DISPLAY	√	√	√	√			
GENERAL	COLT CABRIOLET	RHT/TOPSTACK	√	√	√	√	√	1.Studying 2.Function Test	1.CODING
GENERAL	COLT T120SS	ENGINE	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	ENGINE	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	ABS	√	√	√	√	√	1.YAW rate Sensor type reset 2.Emissions Gas Mode(*) 3.SAS Calibration(*)	
GENERAL	COLT/COLT PLUS	SRS	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	SWS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	COLT/COLT PLUS	AC	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	METER	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	ETACS	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	IMMO	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	AT	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	POWER GATE	√	√	√				
GENERAL	DELICA D:5	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	DELICA D:5	AT	√	√	√	√		1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Emission gas mode	
GENERAL	DELICA D:5	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Frozen key	
GENERAL	DELICA D:5	SRS	√	√	√	√	√		



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	DELICA D:5	AC	√	√	√	√	√		
GENERAL	DELICA D:5	METER	√	√	√	√	√	1.Test 2.Head lamp Auto leveling Diag mode(*) 3.Service reminder(*)	
GENERAL	DELICA D:5	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Anti-theft warning device	
GENERAL	DELICA D:5	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	DELICA D:5	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	1.CODING
GENERAL	DELICA D:5	AUTO CRUISE	√	√	√	√			
GENERAL	DELICA D:5	AFS/ACL	√	√	√	√	√		
GENERAL	DELICA D:5	POWER GATE	√	√	√	√	√		
GENERAL	DELICA D:5	LIN	√	√	√	√		Rain sensor adaptation	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	DELICA D:5	ELECTRIC SLIDE DOOR R	√	√	√	√	√		
GENERAL	DELICA D:5	ELECTRIC SLIDE DOOR L	√	√	√	√	√		
GENERAL	DELICA PICK UP	ENGINE	√	√	√	√	√		
GENERAL	DION	ENGINE	√	√	√	√	√		
GENERAL	DION	ABS	√	√	√	√	√		
GENERAL	DION	SRS	√	√	√	√	√		
GENERAL	DION	SWS	√	√	√	√	√		
GENERAL	DION	IMMO	√	√	√	√	√		
GENERAL	DION	AC	√	√	√	√	√		
GENERAL	ECLIPSE	ENGINE	√	√	√	√	√	1.OBD test results (Mode \$06) 2.Learned Value Reset(*) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
GENERAL	ECLIPSE	AT	√	√	√	√	√	1.Test 2.Learn Value Reset(*)	
GENERAL	ECLIPSE	ABS	√	√	√	√	√	1.Sensor calibration 2.Lateral G sensor calibration 3.SAS Calibration(*) 4.M/C pressure calibration	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ECLIPSE	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
GENERAL	ECLIPSE	SWS	√	√	√	√	√		
GENERAL	ECLIPSE	AC	√	√	√	√	√		
GENERAL	ECLIPSE	METER	√	√	√	√	√		
GENERAL	ECLIPSE	ETACS	√	√	√				
GENERAL	ECLIPSE	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	ECLIPSE	IMMO	√	√	√	√		1.Key registration (bar code number)(*) 2.Key&KOS (Keyless Operation System) key registration (*) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	ECLIPSE	AUTO CRUISE	√	√	√	√			
GENERAL	EXPRESS	ENGINE	√	√	√	√	√		
GENERAL	EXPRESS	ABS	√	√	√	√	√		
GENERAL	EXPRESS	SRS	√	√	√	√	√		
GENERAL	EXPRESS	ETACS	√	√	√	√	√		
GENERAL	EXPRESS	IMMO	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	GALANT (DJ#,DL#,DM#)	ENGINE	√	√	√	√	√	1.OBD test results (Mode \$06) 2.Learned Value Reset(*) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
GENERAL	GALANT (DJ#,DL#,DM#)	AT	√	√	√	√	√	1.Test 2.Learned value reset	
GENERAL	GALANT (DJ#,DL#,DM#)	ABS	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
GENERAL	GALANT (DJ#,DL#,DM#)	SWS	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	AC	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	METER	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	ETACS	√	√	√				

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	GALANT (DJ#,DL#,DM#)	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
GENERAL	GALANT (DJ#,DL#,DM#)	AUTO CRUISE	√	√	√	√			
GENERAL	GALANT (DJ#,DL#,DM#)	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	GALANT(EA#)	ENGINE	√	√	√	√	√		
GENERAL	GALANT(EA#)	ABS	√	√	√	√	√		
GENERAL	GALANT(EA#)	SRS	√	√	√	√	√		
GENERAL	GALANT(EA#)	ETACS	√	√	√	√	√		
GENERAL	GALANT(EA#)	IMMO	√	√	√	√	√		
GENERAL	GALANT(EA#)	AC	√	√	√	√	√		
GENERAL	GALANT(EA#)	AT	√	√	√	√	√		
GENERAL	GALANT(EA#)	AUTO CRUISE	√	√	√	√			
GENERAL	GALANT(EA#)	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	GRANDIS	ENGINE	√	√	√	√	√		
GENERAL	GRANDIS	ABS	√	√	√	√	√		
GENERAL	GRANDIS	SRS	√	√	√	√	√		
GENERAL	GRANDIS	SWS	√	√	√	√	√		
GENERAL	GRANDIS	AC	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	GRANDIS	METER	√	√	√	√	√		
GENERAL	GRANDIS	ETACS	√	√	√	√	√		
GENERAL	GRANDIS	AND	√	√	√	√	√		
GENERAL	GRANDIS	IMMO	√	√	√	√	√		
GENERAL	GRANDIS	AT	√	√	√	√	√		
GENERAL	GRANDIS	AUTO CRUISE	√	√	√	√			
GENERAL	GRANDIS	KEYLESS OPERATION	√	√	√	√			
GENERAL	GRANDIS	SAS	√	√	√	√	√	1.SAS calibration	
GENERAL	GRANDIS	DISPLAY	√	√	√	√	√		
GENERAL	GRANDIS	POWER GATE	√	√	√				
GENERAL	L200 (K5#,K6#,K7#)	ENGINE	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	ABS	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	AT	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	SRS	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	ETACS	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	IMMO	√	√	√	√	√		
GENERAL	L300/DELICA WAGON	ENGINE	√	√	√	√	√		
GENERAL	LANCER(CK#)	ENGINE	√	√	√	√	√		
GENERAL	LANCER(CK#)	ABS	√	√	√	√	√		
GENERAL	LANCER(CK#)	SWS	√	√	√	√	√		
GENERAL	LANCER(CK#)	SRS	√	√	√	√	√		
GENERAL	LANCER(CK#)	AT	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	ENGINE	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER(CS#,CT#)	SWS	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	ABS	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	SRS	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	IMMO	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	AT	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	AC	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	AUTO CRUISE	√	√	√	√			
GENERAL	LANCER(CS#,CT#)	AYC/ACD	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	LANCER/LANCER EX(CY#)	AT	√	√	√	√	√	1.Teach-In 2.Learn Value Reset 3.Test 4.CVT oil degradation level(*) 5.Electronic oil pump air bleeding 6.Emission gas mode	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER/LANCER EX(CY#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
GENERAL	LANCER/LANCER EX(CY#)	SRS	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	AC	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
GENERAL	LANCER/LANCER EX(CY#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
GENERAL	LANCER/LANCER EX(CY#)	SAS	√	√	√	√	√	1.SAS calibration(*)	



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER/LANCER EX(CY#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	
GENERAL	LANCER/LANCER EX(CY#)	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion learing	
GENERAL	LANCER/LANCER EX(CY#)	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	LANCER/LANCER EX(CY#)	AND	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	AUDIO	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	OCM	√	√	√	√	√	1.Zero Calibration&Sys Check	
GENERAL	LANCER/LANCER EX(CY#)	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER/LANCER EX(CY#)	HFM	√	√	√	√			
GENERAL	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	LANCER EVOLUTION	AT	√	√	√	√	√	1.Teach-In	
GENERAL	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Valve pressure learning 2.Emissions Gas Mode 3.Sensor Calibration(*)	
GENERAL	LANCER EVOLUTION	SRS	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	AC	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER EVOLUTION	ETACS	√	√	√	√		1.Alarm record(*) 2.Customization 3.Customization information 4.Customization reset(*)	
GENERAL	LANCER EVOLUTION	SWS	√	√	√				
GENERAL	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	1.CODING
GENERAL	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
GENERAL	LANCER EVOLUTION	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
GENERAL	LANCER EVOLUTION	HFM	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	AYC/ACD	√	√	√	√	√	1.Test 2.Sensor Calibration(*) 3.Air bleeding	
GENERAL	LANCER EVOLUTION	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	LANCER EVOLUTION	AND	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	LANCER EVOLUTION	AUDIO	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	OCM	√	√	√	√	√	1.Zero Calibration&Sys Check	
GENERAL	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	LANCER SPORTBACK	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Teach-in 4.Emission gas mode	
GENERAL	LANCER SPORTBACK	ABS	√	√	√	√	√	1.Frozen key 2.Emissions Gas Mode(*) 3.SAS Calibration(*)	
GENERAL	LANCER SPORTBACK	SRS	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	AC	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
GENERAL	LANCER SPORTBACK	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	ETACS	√	√	√	√		1.Alarm record(*) 2.Customization 3.Customization information 4.Customization reset(*)	
GENERAL	LANCER SPORTBACK	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	LANCER SPORTBACK	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	1.CODING
GENERAL	LANCER SPORTBACK	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER SPORTBACK	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
GENERAL	LANCER SPORTBACK	AYC/ACD	√	√	√	√	√	1.Test 2.Sensor Calibration(*) 3.Air bleeding	
GENERAL	LANCER SPORTBACK	AND	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	LANCER SPORTBACK	AUDIO	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	HFM	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	SHIFT LEVER	√	√	√	√	√		
GENERAL	LANCER WAGON	ENGINE	√	√	√	√	√		
GENERAL	LANCER WAGON	ABS	√	√	√	√	√		
GENERAL	LANCER WAGON	SRS	√	√	√	√	√		
GENERAL	LANCER WAGON	SWS	√	√	√	√	√		
GENERAL	LANCER WAGON	AC	√	√	√	√	√		
GENERAL	LANCER WAGON	IMMO	√	√	√	√	√		
GENERAL	LANCER WAGON	AUTO CRUISE	√	√	√	√			
GENERAL	LANCER WAGON	AT	√	√	√	√	√		
GENERAL	MAVEN	ENGINE	√	√	√	√	√		
GENERAL	MINICAB-MiEV	ABS	√	√	√	√			
GENERAL	MINICAB-MiEV	SRS	√	√	√	√			
GENERAL	MINICAB-MiEV	METER	√	√	√	√			
GENERAL	MINICAB-MiEV	ETACS	√	√	√	√			
GENERAL	MINICAB-MiEV	4WS/Electric Power Steering	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	MINICAB-MiEV	EV-ECU	√	√	√	√			
GENERAL	MINICAB-MiEV	BMU	√	√	√	√			
GENERAL	MINICAB-MiEV	MCU	√	√	√	√			
GENERAL	MINICAB-MiEV	COMP&HTR	√	√	√	√			
GENERAL	MINICAB-MiEV	CMU	√			√			
GENERAL	MIRAGE/SPACE STAR	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	MIRAGE/SPACE STAR	AT	√	√	√	√	√	1.Emission gas mode 2.Learn Value Reset 3.Sensor calibration 4.CVT oil degradation level 5.Electronic oil pump air bleeding 6.Reset	
GENERAL	MIRAGE/SPACE STAR	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
GENERAL	MIRAGE/SPACE STAR	SRS	√	√	√	√	√		CODING
GENERAL	MIRAGE/SPACE STAR	AC	√	√	√	√	√		
GENERAL	MIRAGE/SPACE STAR	4WS/Electric Power Steering	√	√	√	√	√		





## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(CU#)	SRS	√	√	√	√	√		
GENERAL	OUTLANDER(CU#)	SWS	√	√	√	√	√		
GENERAL	OUTLANDER(CU#)	AT	√	√	√	√	√		
GENERAL	OUTLANDER(CU#)	AC	√	√	√	√	√		
GENERAL	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			
GENERAL	OUTLANDER(CU#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Permit condition for AS&G 4.Emission gas mode	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Frozen key	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	SRS	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AC	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	SAS	√	√	√			1.SAS calibration(*)	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	1.CODING
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AND	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	MULTI SELECT 4WD	√	√	√	√		Test	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AUDIO	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(GF#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.In-use performance tracking(OBD) 7.Write learned value(changed ECU) 8.DPF regeneration 9.In-use performance tracking(ENH) 10.Timing chain maintenance 11.Learned value reset 12.Ethanol forced learning mode	1.CODING 2.READINESS TEST
GENERAL	OUTLANDER(GF#)	AT	√	√	√	√		1.Emission gas mode 2.Electronic oil pump air bleeding 3.CVT oil degradation level 4.Permit condition for AS&G	
GENERAL	OUTLANDER(GF#)	ABS	√	√	√	√			
GENERAL	OUTLANDER(GF#)	AC	√	√	√	√			
GENERAL	OUTLANDER(GF#)	SRS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(GF#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
GENERAL	OUTLANDER(GF#)	ETACS	√	√	√	√			
GENERAL	OUTLANDER(GF#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	
GENERAL	OUTLANDER(GF#)	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Key registration 4.Key registration (bar code number) 5.Engine Key Code registration 6.ENGINE KEY CODE registration&VIN WRITING 7.Comm. Test 8.KOS Key registration	
GENERAL	OUTLANDER(GF#)	AUTO CRUISE	√	√	√	√			
GENERAL	OUTLANDER(GF#)	4WS/Electric Power Steering	√	√	√	√			
GENERAL	OUTLANDER(GF#)	SAS	√	√	√	√			
GENERAL	OUTLANDER(GF#)	LIN	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(GF#)	AS&G	√	√	√	√			
GENERAL	OUTLANDER(GF#)	AWC	√	√	√	√			
GENERAL	OUTLANDER(GF#)	OSS	√	√	√	√			
GENERAL	OUTLANDER(GF#)	AND	√	√	√	√			
GENERAL	OUTLANDER(GF#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
GENERAL	OUTLANDER(GF#)	AUDIO	√	√	√	√			
GENERAL	OUTLANDER(GF#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
GENERAL	OUTLANDER(GF#)	OCM	√	√	√	√			
GENERAL	OUTLANDER(GF#)	Power Gate	√	√	√	√			
GENERAL	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	OUTLANDER-PHEV	ABS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	AC	√	√	√	√			
GENERAL	OUTLANDER-PHEV	SRS	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
GENERAL	OUTLANDER-PHEV	ETACS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING
GENERAL	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			
GENERAL	OUTLANDER-PHEV	SAS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	LIN	√	√	√	√			
GENERAL	OUTLANDER-PHEV	BMU	√	√	√	√			
GENERAL	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
GENERAL	OUTLANDER-PHEV	OSS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	AND	√	√	√	√			
GENERAL	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
GENERAL	OUTLANDER-PHEV	AUDIO	√	√	√	√			
GENERAL	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
GENERAL	OUTLANDER-PHEV	Compressor	√	√	√	√			
GENERAL	OUTLANDER-PHEV	F-MCU	√	√	√	√			
GENERAL	OUTLANDER-PHEV	GCU	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER-PHEV	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
GENERAL	OUTLANDER-PHEV	OBC	√	√	√	√			
GENERAL	OUTLANDER-PHEV	P LOCK	√	√	√	√			
GENERAL	OUTLANDER-PHEV	Power Gate	√	√	√	√			
GENERAL	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
GENERAL	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
GENERAL	OUTLANDER-PHEV	CMU	√			√			
GENERAL	PAJERO/MONTERO(V6#,V7#)	ENGINE	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AT	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	ABS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SWS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		



## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V6#,V7#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	HBB	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	
GENERAL	PAJERO/MONTERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Learn valued Reset(*) 2.Initialize 3.Injector ID Writing(Exchanging Injector) 4.Injector ID Readout	1.READINESS TEST 2.CODING
GENERAL	PAJERO/MONTERO(V8#,V9#)	AT	√	√	√	√	√	1.Learn value test 2.Test	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ABS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	SWS	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V8#,V9#)	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	METER	√	√	√	√	√	1.Service reminder	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ETACS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	PAJERO/MONTERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	HBB	√	√	√		√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	DISPLAY	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	LIN	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	CAN/LIN/SWS CONVERTER	√	√	√	√		1.Customization 2.Customization information 3.Reset	



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	ENGINE	√	√	√	√	√	1.Initialization(Supply pump exchange service)(*) 2.Test(Fuel system leak detection) 3.Learning(Micro injection adaptation) 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout	1.READINESS TEST 2.CODING
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	SRS	√	√	√	√	√		
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	AT	√	√	√	√	√	1.Learn Value Reset 2.Test	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	DISPLAY	√	√	√	√			
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	LIN	√	√	√	√			
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.key registration (Use Key) 4.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	TRITON/L200(KA#,KB#)/STRADA(KA#,KB#)	AC	√	√	√	√	√		
GENERAL	ZINGER/FUZION	ENGINE	√	√	√	√	√	1.Initialization(Supply pump exchange service)(*) 2.Test(Fuel system leak detection) 3.Learning(Micro injection adaptation) 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Temporary DTC	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ZINGER/FUZION	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	ZINGER/FUZION	SRS	√	√	√	√	√		
GENERAL	ZINGER/FUZION	AT	√	√	√	√	√		
GENERAL	ZINGER/FUZION	ABS	√	√	√	√	√		
GENERAL	ZINGER/FUZION	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	ENGINE	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AT	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	ABS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SWS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V6#,V7#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	HBB	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	IMMO	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Write learned value(Changed ECU) 8.Learning value reset 9.OBD test results (Mode \$06) 10.In-use performance tracking(ENH) 11.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Nota:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V8#,V9#)	AT	√	√	√	√	√	1.Learn value test 2.Test	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ABS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	SWS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	AC		√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	METER	√	√	√	√	√	1.Service reminder	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ETACS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	PAJERO/MONTERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	HBB	√	√	√		√		



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V8#,V9#)	DISPLAY	√	√	√				
GENERAL	PAJERO/MONTERO(V8#,V9#)	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	PAJERO/MONTERO(V8#,V9#)	CAN/LIN/SWS CONVERTER	√	√	√	√		1.Customization 2.Customization information 3.Reset	
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	ENGINE	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	ABS	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	SRS	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	ETACS	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	AT	√	√	√	√	√		

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	AC	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	IMMO	√	√	√	√	√		
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Learning value reset	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	AT	√	√	√	√	√	1.Test 2.Learning value reset	

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	ABS	√	√	√	√	√	Lateral G Sensor Calibration	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	AC	√	√	√	√	√		
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	SRS		√	√	√	√		
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	AUTO CRUISE	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH #)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH #)	DISPLAY	√	√	√				
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH #)	SAS	√	√	√			SAS Calibration	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH #)	LIN	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions							
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	IMMO	√	√	√	√			1.Change password 2.Key registration (bar code number) 3.Key registration (using key) 4.ENGINE KEY CODE registration&VIN WRITING 5.Key Code agreement	1.CODING
GENERAL	PAJERO IO / PAJERO TR4	ENGINE	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	AT	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	ABS	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	SRS	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	SWS	√	√	√	√	√			
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	ENGINE	√	√	√	√	√		1.Initialization 2.Test 3.Learning 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Learning value reset	1.READINESS TEST 2.CODING

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	ABS	√	√	√	√	√		
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	SRS		√	√	√	√		
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	AT	√	√	√	√	√	1.Learn Value Reset 2.Test	
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	DISPLAY	√	√	√				
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	SAS	√	√	√			SAS Calibration	
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	LIN	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions							
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others	
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	IMMO	√	√	√	√			1.Change password 2.Key registration (bar code number) 3.Key registration (using key) 4.ENGINE KEY CODE registration&VIN WRITING 5.Key Code agreement	1.CODING
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	AC	√	√	√	√	√			
GENERAL	ZINGER/FUZION	ENGINE	√	√	√	√	√		1.Initialization 2.Test 3.Learning 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Learning value reset	1.READINESS TEST 2.CODING
GENERAL	ZINGER/FUZION	ETACS	√	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	ZINGER/FUZION	SRS		√	√	√	√			
GENERAL	ZINGER/FUZION	AT	√	√	√	√	√			

## Mitsubishi V31.40 Diagnostics List( Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ZINGER/FUZION	ABS	√	√	√	√	√		
GENERAL	ZINGER/FUZION	AC		√	√	√	√		
GENERAL	I	ENGINE	√	√	√	√	√	1.Learned value reset(*)	1.READINESS TEST
GENERAL	I	AT	√	√	√	√	√	1.Learned value reset	
GENERAL	I	ABS	√	√	√	√	√		
GENERAL	I	SRS		√	√	√	√		
GENERAL	I	AC		√	√	√	√		
GENERAL	I	METER	√	√	√	√	√	1.Service reminder(*)	
GENERAL	I	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	I	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	I	LIN	√	√	√	√			
GENERAL	I	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
GENERAL	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	
GENERAL	I-MIEV	SRS		√	√	√	√		
GENERAL	I-MIEV	AC		√	√	√	√		



## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	I-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	
GENERAL	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	I-MIEV	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
GENERAL	I-MIEV	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password 5.Key Code agreement	1.CODING
GENERAL	I-MIEV	LIN	√	√	√	√			
GENERAL	I-MIEV	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	

## Mitsubishi V31.40 Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	
GENERAL	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
GENERAL	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	
GENERAL	I-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	
GENERAL	I-MIEV	CMU	√			√		1.Reset	
GENERAL	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	

(\*):Tested;