

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Amarok	2010 >	2H	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Caddy	1996 > 2003	9K	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Caddy	2004>2010	2K	16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			3D Special Function	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
7D Auxiliary Heater	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Caddy	2011 >	2C	44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Corrado	< 1995	50	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Golf Cabrio	1993 > 2002	1E	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Golf Cabrio	1997 > 2002	1V	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			35 Central Locking	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Golf Cabrio	2012 >	51	03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Eos	2006>	1F	01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			1C Vehicle Position Detection	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			26 Electric roof control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			63 DRVS BOARDING ASS1	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			73 DRVS BOARDING ASS2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Eos NAR	2010 >	AH	46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,S01,S02,S03,S07
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S07



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Fox	2004 >	5Z	08 AC/Heating electronics	B01,B02,B03,B04,S01,S02,S03,S07
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,S01,S02,S03,S07
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S07
			19 Gateway data bus	B01,B02,B03,B04,S01,S02,S03,S07
			44 Steering assistance	B01,B02,B03,B04,S01,S02,S03,S07
			46 Central Control Module	B01,B02,B03,B04,S01,S02,S03,S07
			56 Radio	B01,B02,B03,B04,S01,S02,S03,S07
Golf Citi	< 2009	17	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Golf/Jetta II	1989 > 1992	1G	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Golf/Vento III	1992>1999	1H	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			12 Clutch electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			41 Diesel pump electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Golf/Bora IV	1998>2006	1J	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			36 Driver`s side seat adj.	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			47 Soundsystem	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			55 Headlight range control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			57 TV-TUNER	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
76 Parking aid	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			
			01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Jetta IV	1998 > 2014	9M	08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			36 Driver`s side seat adj.	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			47 Soundsystem	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			55 Headlight range control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			57 TV-TUNER	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
76 Parking aid	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			0F Radio Tuner-Digital	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Golf/Jetta V	2004>2009	1K	15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			1C Vehicle Position Detection	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			3D Special Function	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			4F Electronic central electric II	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
57 TV-TUNER	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
65 Tyre pressure monitoring	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			76 Parking aid	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			7D Auxiliary Heater	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
Golf/Jetta VI	2009>2013	5K	01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			0F Radio Tuner-Digital	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			14 Wheel damping electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			1C Vehicle Position Detection	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			4F Electronic central electric II	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			5F Information Electronic Equipm	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Golf/Jetta VI NAR	2010 > 2013	AJ	55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Golf/Jetta VII	2013 >	5G	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Golf Variant VII	2014>	BA	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Gol/Par/Sav/Poi	>2005	5W	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Gol/Par/Sav/Poi		5X	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Gol Special		5Y	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Gol/Voyage/Saveiro	> 2005	5U	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Novo Gol/Voyage	> 2005	5U	03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
			01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
New Beetle	1998 > 2010	1C	17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			26 Electric roof control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			54 Rear spoiler	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
New Beetle NAR	2010	AG	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			26 Electric roof control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			54 Rear spoiler	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
New Beetle	1999 > 2010	9C	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			26 Electric roof control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			54 Rear spoiler	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
New Beetle Cab	2003 > 2010	1Y	15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			26 Electric roof control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			54 Rear spoiler	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
New Beetle Cab NAR	2010	AL	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			26 Electric roof control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			54 Rear spoiler	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Beetle	2012 >	5C	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Beetle NAR	2012 >	AT	19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Beetle Cab	2013 >	5C	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Beetle Cab NAR	2013 >	AT	55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
New Bora	2008 >	15	15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S08
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
Lavida	2008 >	18	01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
LT3	2006>	2E	91 Engine	B01,B02,B03,B04,B07,S01,S02,S03,S04,S05,S06,S08,S09
			93 Immo	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			94 Airbag	B01,B02,B03
			95 ESP	B01,B02,B03
			96 Instruments	B01,B02,B03
			99 Lgn.Switch	B01,B02,B03
			9A Central Locks	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			9B Driver Door	B01,B02,B03
			B3 Trailer Module	B01,B02,B03

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			B4 Central ELEC	B01,B02,B03
			B6 Steering Wheel	B01,B02,B03
Lupo	1998>2006	6X	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			45 Interior Monitoring	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			55 Headlight range control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Passat B3	< 1994	31	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
Passat B4	1994>1997	3A	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			41 Diesel pump electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Passat B5	1997>2005	3B	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			36 Driver`s side seat adj.	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			47 Soundsystem	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			55 Headlight range control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			57 TV-TUNER	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			58 Auxiliary Fuel Tank	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			75 Emergency call module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
76 Parking aid	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			
77 TELEPHONE	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Passat B6	2005>2010	3C	08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			0F Radio Tuner-Digital	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			1C Vehicle Position Detection	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			3D Special Function	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
53 Parking Brake	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			5D Opertion	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			6C Rear Camera	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			6D Electronic Equipment of Trunk	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			7D Auxiliary Heater	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Passat B6 NAR	2010	AN	55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Passat B7	2011 >	36	34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Passat NMS NAR	2012 >	A3	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			0F Radio Tuner-Digital	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			14 Wheel damping electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Passat CC	2009>	35	16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			1C Vehicle Position Detection	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			4F Electronic central electric II	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			53 Parking Brake	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			5C Lane Keeping Assistance System	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
65 Tyre pressure monitoring	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
6C Rear Camera	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Passat CC NAR	2010 >	AN	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			06 PASSENE. SEAT ADJ.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			11 Engine electronics 2	B01,B02,B03,B04,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,S01,S02,S03,S05,S06



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Phaeton	2002>2006	3D	23 BRAKER BOOSTER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			27 DIS./CTL UNIT REAR	B01,B02,B03,B04,S01,S02,S03,S05,S06
			28 Climate Control Unit Rear	B01,B02,B03,B04,S01,S02,S03,S05,S06
			29 Left light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,S01,S02,S03,S05,S06
			34 Self leveling suspension	B01,B02,B03,B04,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,S01,S02,S03,S05,S06
			38 ROOF ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06
			39 Right light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,S01,S02,S03,S05,S06
			47 Soundsystem	B01,B02,B03,B04,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,S01,S02,S03,S05,S06
			66 Seat-/mirror adjust.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			68 WIPER ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,S01,S02,S03,S05,S06
			71 Battery charger	B01,B02,B03,B04,S01,S02,S03,S05,S06
75 Emergency call module	B01,B02,B03,B04,S01,S02,S03,S05,S06			
76 Parking aid	B01,B02,B03,B04,S01,S02,S03,S05,S06			
77 TELEPHONE	B01,B02,B03,B04,S01,S02,S03,S05,S06			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Phaeton	2007 >	3D	03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Polo 86C	1991 > 1994	80	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			45 Interior Monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
			01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Polo	1995>2002	6N	19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			41 Diesel pump electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			45 Interior Monitoring	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			55 Headlight range control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Polo	2002 > 2010	9N	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			44 Steering assistance	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			45 Interior Monitoring	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			76 Parking aid	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Polo	2010 >	6R	08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
Polo Classic	1996 > 2010	6V	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Polo India	2010 >	60	03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Polo Russia	2011 >	61	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Polo Vivo	2010 >	6S	08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			45 Interior Monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Sagitar	2006 >	BK	76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Santana	1994 > 2014	3X	15 Airbags	B01,B02,B03,B04
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Scirocco	2009>	13	01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			14 Wheel damping electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			3D Special Function	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08			



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
Sharan I	1996>2010	7M	25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			18 Aux heating	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			29 Left light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			36 Driver`s side seat adj.	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			39 Right light control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
45 Interior Monitoring	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			
46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			55 Headlight range control	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			76 Parking aid	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Sharan II	2011 >	7N	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Tiguan	2008>	5N	25 Immobilizer	B01,B02,B03
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			4F Electronic central electric II	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			53 Parking Brake	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			6C Rear Camera	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Tiguan NAR	2010>	AX	15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			4F Electronic central electric II	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			53 Parking Brake	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
6C Rear Camera	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Touareg	2003 > 11/2006	7L	01 Engine electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			06 PASSENE. SEAT ADJ.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			11 Engine electronics 2	B01,B02,B03,B04,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,S01,S02,S03,S05,S06
			1C Vehicle Position Detection	B01,B02,B03,B04,S01,S02,S03,S05,S06
			22 4WD Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			29 Left light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			32 Locking Electronisc	B01,B02,B03,B04,S01,S02,S03,S05,S06
			34 Self leveling suspension	B01,B02,B03,B04,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,S01,S02,S03,S05,S06
			39 Right light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,S01,S02,S03,S05,S06
46 Central Control Module	B01,B02,B03,B04,S01,S02,S03,S05,S06			
47 Soundsystem	B01,B02,B03,B04,S01,S02,S03,S05,S06			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			55 Headlight range control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			64 Stabilizers	B01,B02,B03,B04,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,S01,S02,S03,S05,S06
			68 WIPER ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,S01,S02,S03,S05,S06
			6C Rear Camera	B01,B02,B03,B04,S01,S02,S03,S05,S06
			6D Electronic Equipment of Trunk	B01,B02,B03,B04,S01,S02,S03,S05,S06
			6E Roof Display/Control Head	B01,B02,B03,B04,S01,S02,S03,S05,S06
			75 Emergency call module	B01,B02,B03,B04,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,S01,S02,S03,S05,S06
Touareg	12/2006 > 2011	7L	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			06 PASSENE. SEAT ADJ.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			11 Engine electronics 2	B01,B02,B03,B04,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,S01,S02,S03,S05,S06
			1C Vehicle Position Detection	B01,B02,B03,B04,S01,S02,S03,S05,S06



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Touareg NAR	2010>2011	A9	22 4WD Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			29 Left light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			32 Locking Electronisc	B01,B02,B03,B04,S01,S02,S03,S05,S06
			34 Self leveling suspension	B01,B02,B03,B04,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,S01,S02,S03,S05,S06
			39 Right light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,S01,S02,S03,S05,S06
			47 Soundsystem	B01,B02,B03,B04,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			64 Stabilizers	B01,B02,B03,B04,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,S01,S02,S03,S05,S06
			68 WIPER ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,S01,S02,S03,S05,S06
			6C Rear Camera	B01,B02,B03,B04,S01,S02,S03,S05,S06
			6D Electronic Equipment of Trunk	B01,B02,B03,B04,S01,S02,S03,S05,S06
			6E Roof Display/Control Head	B01,B02,B03,B04,S01,S02,S03,S05,S06
			75 Emergency call module	B01,B02,B03,B04,S01,S02,S03,S05,S06
76 Parking aid	B01,B02,B03,B04,S01,S02,S03,S05,S06			
77 TELEPHONE	B01,B02,B03,B04,S01,S02,S03,S05,S06			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Touareg	2011 >	7P	03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Touareg NAR	2011 >	BP	65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Touran	2003>	1T	16 Steering Wheel Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			3D Special Function	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			44 Steering assistance	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			46 Central Control Module	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
7D Auxiliary Heater	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
Transporter	1991 > 1996	70	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			15 Airbags	B01,B02,B03,B04
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
Transporter	1996>2004	7D	01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			25 Immobilizer	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			35 Central Locking	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			01 Engine electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			02 Transmission Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			03 Brake Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			08 AC/Heating electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			0B Auxiliary Air Heater	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			0D Sliding Door Left	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			17 Instrument Cluster	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Transporter	1996>2004	7H	18 Aux heating	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			19 Gateway data bus	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			1C Vehicle Position Detection	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			22 4WD Electronics	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			2D Voice Amplification	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			37 Navigation	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			45 Interior Monitoring	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			46 Central Control Module	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			47 Soundsystem	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			56 Radio	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			57 TV-TUNER	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			6E Roof Display/Control Head	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			76 Parking aid	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			77 TELEPHONE	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
			78 SLIDING DOOR	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09
7D Auxiliary Heater	B01,B02,B03,B04,B06,B08,S01,S02,S03,S04,S07,S09			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Transporter/Multivan	2003 > 2010	7J	22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
			01 Engine electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			0B Auxiliary Air Heater	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			0D Sliding Door Left	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			10 Parking Assist System 2	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			17 Instrument Cluster	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Transporter	2010>	7E	19 Gateway data bus	B01,B02,B03,B04,B07,S01,S02,S03,S05,S08
			22 4WD Electronics	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			25 Immobilizer	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2D Voice Amplification	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			47 Soundsystem	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			6C Rear Camera	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			6E Roof Display/Control Head	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06
78 SLIDING DOOR	B01,B02,B03,B04,B07,S01,S02,S03,S05,S06			
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0B Auxiliary Air Heater	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0D Sliding Door Left	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			10 Parking Assist System 2	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			13 Distance control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Transporter/Multivan	2010 >	7F	17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			18 Aux heating	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			2D Voice Amplification	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			2E Media player position 3	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			47 Soundsystem	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			57 TV-TUNER	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			69 TRAILER FUNCTION	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			6C Rear Camera	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			6E Roof Display/Control Head	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			77 TELEPHONE	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			78 SLIDING DOOR	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
Up	2012 >	12	44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Up	2012 >	AA	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			02 Transmission Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			03 Brake electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			08 AC/Heating electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			25 Immobilizer	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			34 Self leveling suspension	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			44 Steering assistance	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			17 Instrument Cluster	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			19 Gateway data bus	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			37 Navigation	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			46 Central Control Module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			76 Parking aid	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			55 Headlight range control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			56 Radio	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			65 Tyre pressure monitoring	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
53 Parking Brake	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
22 4WD Electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			
26 Electric roof control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08			

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			29 Left light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			39 Right light control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			75 Emergency call module	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			42 DRIVER-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			52 PASSE.-DOOR ELECT.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			62 LR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			72 RR-DOOR ELECTRONI.	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			0E Media player position 1	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			4F Electronic central electric II	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			3C Lane Departure Assistance Sys	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			5F Information Electronic Equipm	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
			61 Battery control	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Marine Engines	ALL	MA	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08
Industrial Engines	ALL	IN	01 Engine electronics	B01,B02,B03,B04,B05,B06,B07,S01,S02,S03,S04,S05,S06,S07,S08

**NOTE:**

Basic Functions	Special Functions
B01: Control Unit Info	S01: Output Tests
B02: Read Fault Codes	S02: Basic Settings
B03: Clear Fault Codes	S03: Adaptation
B04: Measuring Blocks (Live Data)	S04: Login
B05: Read FreFrame	S05: Access permission
B06: Readiness	S06: Coding II
B07: identification services	S07: Code Module
B08: Single Reading	S08: Long Code
	S09: Chassis Number adjustment

**Volkswagen V27.15 Diagnostics List** (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
-------	------	------	---------	-----------

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

**Volkswagen V27.15 Diagnostics List**(Note:For reference only)

Year	System Type	TOCOL T	Systems	Functions
			01 Engine electronics	
			11 Engine electronics 2	
			21 Engine electronics 3	
			02 Transmission Electronics	
			03 Brake Electronics	
			08 AC/Heating electronics	
			25 Immobilizer	
			47 Soundsystem	
			12 Clutch electronics	
			34 Self leveling suspension	
			15 Airbags	
			16 Steering Wheel Electronics	
			44 Steering assistance	
			35 Central Locking	
			14 Wheel damping electronics	
			17 Instrument Cluster	
			18 Aux heating	
			13 Distance control	
			19 Gateway data bus	
			26 Electric roof control	

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			29 Left light control	
			39 Right light control	
			37 Navigation	
			45 Interior Monitoring	
			46 Central Control Module	
			49 Auto. Lighting switch	
			51 Electric drive	
			61 Battery control	
			75 Emergency call module	
			76 Parking aid	
			09 Electronic Ctrl Electronics	
			22 4WD Electronics	
			24 Drive slip control	
			36 Driver`s side seat adj.	
			41 Diesel pump electronics	
			55 Headlight range control	
			56 Radio	
			65 Tyre pressure monitoring	
			66 Seat-/mirror adjust.	B01: Control Unit Info
			71 Battery charger	B02: Read Fault Codes
			42 DRIVER-DOOR ELECT.	B03: Clear Fault Codes
			52 PASSE.-DOOR ELECT.	B04: Measuring Blocks (Live Data)
			62 LR-DOOR ELECTRONI.	B05: Read FreFrame
			72 RR-DOOR ELECTRONI.	B06: Readiness
			23 BRAKER BOOSTER	B07: identification services
				B08: Single Reading

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
		BOSCH	43 BRAKER BOOST.ASSI.	008: Single Reading
			63 DRVS BOARDING ASS1	S01: Output Tests
			73 DRVS BOARDING ASS2	S02: Basic Settings
			54 Rear spoiler	S03: Adaptation
			05 ACCESS & PERMISSI.	S04: Login
			06 PASSENE. SEAT ADJ.	S05: Access permission
			07 DISPLAY-/CNTL UNIT	S06: Coding II
			27 DIS./CTL UNIT REAR	S07: Code Module
			57 TV-TUNER	S08: Long Code
			67 VOICE CONTROL	S09: Chassis Number adjustment
			77 TELEPHONE	
			38 ROOF ELECTRONICS	
			48 DRVS SEAT ADJ.REAR	
			68 WIPER ELECTRONICS	
			78 SLIDING DOOR	
			59 TOWING PROTECTION	
			69 TRAILER FUNCTION	
			28 Climate Control Unit Rear	
			31 Engine Electronics Conjunct.	
			32 Locking Electronisc	
		53 Parking Brake		
		58 Auxiliary Fuel Tank		
		64 Stabilizers		
		1C Vehicle Position Detection		
		2D Voice Amplification		



## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			3D Special Function	
			6E Roof Display/Control Head	
			7E Ind.Unit in Inst.Panel Ins.	
			0D Sliding Door Left	
			7D Auxiliary Heater	
			0F Radio Tuner-Digital	
			1F Radio Satellite	
			2F TV Tuner-Digital	
			04 Steering Position	
			74 Vehicle Control System	
			3C Lane Departure Assistance Sys	
			4C Tyre Pressure Monitor II	
			5C Lane Keeping Assistance System	
			6C Rear Camera	
			5D Opertion	
			6D Electronic Equipment of Trunk	
			0B Auxiliary Air Heater	
			5F Information Electronic Equipm	
			6F Confort Central Control Unit II	
			1B Power-Assisted Steering	
			10 Parking Assist System 2	
			BF Sliding Door Right	
	Without CAN BUS		01 Engine electronics	
			11 Engine electronics 2	
			21 Engine electronics 3	

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			02 Transmission Electronics	
			03 Brake Electronics	
			08 AC/Heating electronics	
			25 Immobilizer	
			47 Soundsystem	
			12 Clutch electronics	
			34 Self leveling suspension	
			15 Airbags	
			16 Steering Wheel Electronics	
			44 Steering assistance	
			35 Central Locking	
			14 Wheel damping electronics	
			17 Instrument Cluster	
			18 Aux heating	
			13 Distance control	
			19 Gateway data bus	
			26 Electric roof control	
			29 Left light control	
			39 Right light control	
			37 Navigation	
			45 Interior Monitoring	
			46 Central Control Module	
			49 Auto. Lighting switch	
			51 Electric drive	
			61 Battery control	

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
before 2007		KWP 2	75 Emergency call module	
			76 Parking aid	
			09 Electronic Ctrl Electronics	
			22 4WD Electronics	
			24 Drive slip control	
			36 Driver`s side seat adj.	
			41 Diesel pump electronics	
			55 Headlight range control	
			56 Radio	
			65 Tyre pressure monitoring	
			66 Seat-/mirror adjust.	
			71 Battery charger	
			42 DRIVER-DOOR ELECT.	01 Control Unit Info
			52 PASSE.-DOOR ELECT.	02 Read Fault Codes
			62 LR-DOOR ELECTRONI.	08 Measuring Blocks (Live Data)
			72 RR-DOOR ELECTRONI.	05 Clear Fault Codes
			23 BRAKER BOOSTER	04 Basic Settings
			43 BRAKER BOOST.ASSI.	03 output tests
			63 DRVS BOARDING ASS1	10 adaptation
			73 DRVS BOARDING ASS2	11 code module
			54 Rear spoiler	16 Access permission
			05 ACCESS & PERMISSI.	
			06 PASSENE. SEAT ADJ.	
07 DISPLAY-/CNTL UNIT				
27 DIS./CTL UNIT REAR				

**Volkswagen V27.15 Diagnostics List** (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			57 TV-TUNER	
			67 VOICE CONTROL	
			77 TELEPHONE	
			38 ROOF ELECTRONICS	
			48 DRVS SEAT ADJ.REAR	
			68 WIPER ELECTRONICS	
			78 SLIDING DOOR	
			59 TOWING PROTECTION	
			69 TRAILER FUNCTION	
			28 Climate Control Unit Rear	
			31 Engine Electronics Conjunct.	
			32 Locking Electronisc	
			53 Parking Brake	
			58 Auxiliary Fuel Tank	
			64 Stabilizers	
			1C Vehicle Position Detection	
			2D Voice Amplification	
			3D Special Function	
			6E Roof Display/Control Head	
			7E Ind.Unit in Inst.Panel Ins.	
			0D Sliding Door Left	
			7D Auxiliary Heater	
			0F Radio Tuner-Digital	
			1F Radio Satellite	
			2F TV Tuner-Digital	

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			04 Steering Position	
			74 Vehicle Control System	
			3C Lane Departure Assistance Sys	
			4C Tyre Pressure Monitor II	
			5C Lane Keeping Assistance System	
			6C Rear Camera	
			5D Opertion	
			6D Electronic Equipment of Trunk	
			0B Auxiliary Air Heater	
			5F Information Electronic Equipm	
			6F Confort Central Control Unit II	
			1B Power-Assisted Steering	
			10 Parking Assist System 2	
			BF Sliding Door Right	
			01 Engine electronics	
			11 Engine electronics 2	
			44 Steering assistance	
			05 ACCESS & PERMISSI.	
			21 Engine electronics 3	
			31 Engine Electronics Conjunct.	
			61 Battery control	
			02 Transmission Electronics	
			22 4WD Electronics	
			42 DRIVER-DOOR ELECT.	
			52 PASSE.-DOOR ELECT.	

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			62 LR-DOOR ELECTRONI.	
			72 RR-DOOR ELECTRONI.	
			03 Brake Electronics	
			13 Distance control	
			53 Parking Brake	
			34 Self leveling suspension	
			15 Airbags	
			25 Immobilizer	
			55 Headlight range control	
			65 Tyre pressure monitoring	
			75 Emergency call module	
			06 PASSENE. SEAT ADJ.	
			16 Steering Wheel Electronics	
			26 Electric roof control	
			36 Driver`s side seat adj.	
			46 Central Control Module	
			56 Radio	
			66 Seat-/mirror adjust.	
			76 Parking aid	B01: Control Unit Info
			1D Driver identification	B02: Read Fault Codes
			3D Special Function	B03: Clear Fault Codes
			07 DISPLAY-/CNTL UNIT	B04: Measuring Blocks (Live Data)
			17 Instrument Cluster	B05: Read FreFrame
			37 Navigation	B06: Readiness
			47 Soundsystem	B07: identification services

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
	CAN BUS	CAN BU	57 TV-TUNER	B08: Single Reading
			67 VOICE CONTROL	S01: Output Tests
			77 TELEPHONE	S02: Basic Settings
			0E Media player position 1	S03: Adaptation
			1E Media player position 2	S04: Login
			2E Media player position 3	S05: Access permission
			3E Media player position 4	S06: Coding II
			4E Control head RR	S07: Code Module
			5E Control head LR	S08: Long Code
			7E Ind.Unit in Inst.Panel Ins.	S09: Chassis Number adjustment
			08 AC/Heating electronics	
			18 Aux heating	
			28 Climate Control Unit Rear	
			38 ROOF ELECTRONICS	
			7D Auxiliary Heater	
			09 Electronic Ctrl Electronics	
			19 Gateway data bus	
			69 TRAILER FUNCTION	
			0F Radio Tuner-Digital	
			1F Radio Satellite	
			2F TV Tuner-Digital	
			4F Electronic central electric II	
			04 Steering Position	
			74 Vehicle Control System	
			3C Lane Departure Assistance Sys	

## Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
			4C Tyre Pressure Monitor II	
			5C Lane Keeping Assistance System	
			6C Rear Camera	
			5D Operation	
			6D Electronic Equipment of Trunk	
			0B Auxiliary Air Heater	
			5F Information Electronic Equipment	
			6F Comfort Central Control Unit II	
			1B Power-Assisted Steering	
			10 Parking Assist System 2	
			20 High Beam Assistance Device	
			30 Special Function 2	
			BF Sliding Door Right	
		CAN B		Collection services

**NOTE:**The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

CONNECTOR	X431/TOOL	DIAG UN
OBD 16C	VW Model of non-CAN BUS protocol	N/A
CANBUS II	All VW Models with 16PIN DLC	N/A



Volkswagen **V27.15** Diagnostics List (Note:For reference only)

MODEL	YEAR	TYPE	SYSTEMS	FUNCTIONS
SUPER 16	All VW Models with 16PIN DLC	N/A		
diagun connector	N/A	All VW Models with 16PIN DLC		