

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
DEDRA	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD	
		Hitachi MPI Injection	VCDA	
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD	
		Hitachi MPI Injection	VCDA	
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD	
		Hitachi MPI Injection	VCDA	
	'98 1.6 16V	Bosch 5.3 ABS	VCD	
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049	
DELTA (111)	'96 1.6 16V	Bosch 5.3 ABS	VCD	
	'96 1.6 16V	Bosch 5.3 ABS	VCD	
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD	
		Hitachi MPI Injection	VCDA	
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD	
		Hitachi MPI Injection	VCDA	
	'96 2.0 TURBO 16V	Bosch 5.3 ABS	VCD	
	'96 TD	Bosch 5.3 ABS	VCD	
	'98 1.6 16V	Bosch 5.3 ABS	VCD	
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049	
	'98 1.8 16V	Bosch 5.3 ABS	VCD	
		Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001	
		Engine-Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
			Injection Landi Renzo LC02 Gas	VCDA
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.4 TURBO 16V		Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDAS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	1.6 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
			Marelli SELESPEED CFC300 Automatic Gearbox	VCDAS010
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
Comfort		Denso 3 climate control (Two-zone)	VCDAS007	
		Driver's seat Lear 3	VCDA	
	Passenger's seat Lear 3	VCDA		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
DELTA (181)		Other systems	TRW 3 Electric Steering	VCDAS008
			Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	1.8 JTS TB 16V	Engine-Gearbox	Automatic Gearbox AISIN AF40-6	VCDAS011
			Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	VCDAS012
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDAS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
	Valeo Semi-automatic Parking Control Unit		VCDAS056	
		Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.9 MJET 16V TWINTB		Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
	Other systems	Tyre Pressure Control TRW 2	VCDAS057	
		Valeo 2 Parking control unit	VCDAS059	
		Valeo Semi-automatic Parking Control Unit	VCDAS056	
	2.0 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
TRW ABS ESP			VCDAS006	
TRW Lane Control Control Unit (HALF)			VCDA	
Comfort		Denso 3 climate control (Two-zone)	VCDAS007	
	Driver's seat Lear 3	VCDA		
	Passenger's seat Lear 3	VCDA		
	TRW 3 Electric Steering	VCDS008		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
K		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	'98 2.4 JTD	Engine-Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	VCDAS050
			Safety	Bosch 5.3 ABS
		Safety	TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	'99 2.0	Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20V)	VCDAS001
			Safety	Bosch 5.3 ABS
		Safety	TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	'99 2.4	Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20v)	VCDAS001
			Safety	Bosch 5.3 ABS
Safety		TRW MY 97 Air Bag (2F-2P)	VCD	
		TRW MY 97 Air Bag (2F-2P-2L-S)	VCD	
		TRW MY 97 Air Bag (2F-2P-S)	VCD	
99 3.0	Safety	TRW MY 97 Air Bag (2F-2P-2L)	VCD	
		Bosch 5.3 ABS	VCD	
		TRW MY 97 Air Bag (2F-2P)	VCD	
		TRW MY 97 Air Bag (2F-2P-2L-S)	VCD	
		TRW MY 97 Air Bag (2F-2P-S)	VCD	
			TRW MY 97 Air Bag (2F-2P-2L)	VCD

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	2.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.0 TURBO	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4 TD	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
3.0	Safety	Bosch 5.3 ABS	VCD	
		TRW MY 97 Air Bag (2F-2P)	VCD	
		TRW MY 97 Air Bag (2F-2P-2L-S)	VCD	
		TRW MY 97 Air Bag (2F-2P-S)	VCD	
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD	
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD	
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD	
		Allied MY 97 AirBag (2F-2P-I)	VCD	
		Allied MY 97 AirBag (2F-2P-I-S)	VCD	

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	1.6	Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		ESP TRW Lucas ABS	VCDAS013
		Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
	Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD	
	Allied MY 97 AirBag (2F-2P-2L-I)	VCD	
	Allied MY 97 AirBag (2F-2P-I)	VCD	
	Allied MY 97 AirBag (2F-2P-I-S)	VCD	
	Bosch 5.3 ABS	VCD	
	Bosch discharge headlamp (left)	VCDA	
	Bosch discharge headlamp (right)	VCDA	
	ESP TRW Lucas ABS	VCDAS013	
	Hitachi EOBD injection	VCDAS001	
	Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001	
	Marelli Code 2 Electronic Key	VCD	
	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA	
	TRW Lucas ABS	VCDAS015	

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
LYBRA	1.9 JTD	VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	VCDAS050
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch EDC15 CF3/EObD Diesel Injection (eng. 1.9/2.4)	VCDAS016
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
	VAS 97/3 Door Lock RF alarm/receiver	VCD	
	2.0	Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDAS001

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions		
		ESP TRW Lucas ABS	VCDAS013		
		Injection-Bosch Motronic Me3.1 (eng. 2.0/2.4 20v Outside EEC)	VCDAS001		
		Marelli Code 2 Electronic Key	VCD		
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA		
		TRW Lucas ABS	VCDAS015		
		VAS 97/3 Door Lock RF alarm/receiver	VCD		
	2.4 JTD	Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD		
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD		
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD		
		Allied MY 97 AirBag (2F-2P-I)	VCD		
		Allied MY 97 AirBag (2F-2P-I-S)	VCD		
		Bosch 5.3 ABS	VCD		
		Bosch discharge headlamp (left)	VCDA		
		Bosch discharge headlamp (right)	VCDA		
		Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	VCDAS016		
		Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	VCDAS050		
		ESP TRW Lucas ABS	VCDAS013		
		Marelli Code 2 Electronic Key	VCD		
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA		
		TRW Lucas ABS	VCDAS015		
		VAS 97/3 Door Lock RF alarm/receiver	VCD		
				Engine-Gearbox	
				Automatic Gearbox Marelli SELESPEED CFC 308F	VCDAS017
				Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	VCDAS018
				Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055
		Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.3 JTD		Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	VCDAS019
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
			Safety	Bosch 8 ABS
		Bosch 8 VDC ABS		VCDAS045
		Marelli 7 Body Computer		VCDAS047
		Marelli Body Computer 1		VCDAS046
		TRW MY 03 Airbag (2F-2P-2L-2T-I)		VCDA
		TRW MY 03 Airbag (2F-2P-2T-I)		VCDA
		TRW MY 03 Airbag (2F-2P-I)		VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
			Bosch Motronic ME7.3 H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
			Marelli SELESPEED CFC328 Automatic Gearbox	VCDAS024

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions		
	1.4 16V	Instrumentation	Marelli 3 Connect (multi-model)	VCDA		
			Marelli instrument panel (Comfort)	VCDAS020		
			Marelli instrument panel (Modal)	VCDAS021		
		Safety	Bosch 8 ABS	VCD		
			Bosch 8 VDC ABS	VCDAS045		
			Marelli 7 Body Computer	VCDAS047		
			Marelli Body Computer 1	VCDAS046		
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA		
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA		
			TRW MY 03 AirBag (2F-2P-I)	VCDA		
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022		
			Marelli/Microsoft Convergence	VCDAS004		
			TRW 1 Power Steering	VCDAS061		
			TRW 3 Electric Steering	VCDS008		
		Other systems	G.E.PROCOND boot	VCDA		
			G.E.PROCOND Driver's Door	VCDA		
			G.E.PROCOND Passenger Door	VCDA		
			Single BITRON Driver's Door	VCDA		
			Single Driver's Door G.E. PROCOND	VCDA		
			Valeo Parking control unit	VCDS023		
				Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	VCDAS025
				Instrumentation	Marelli 3 Connect (multi-model)	VCDA
					Marelli instrument panel (Comfort)	VCDAS020
Marelli instrument panel (Modal)	VCDAS021					
				Bosch 8 ABS	VCD	

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
MUSA	1.4 8V	Safety	Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
	1.6 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
Bosch 8 VDC ABS			VCDAS045	
Marelli Body Computer			VCD	
TRW MY 03 AirBag (2F-2P-2L-2T-I)			VCDA	
TRW MY 03 AirBag (2F-2P-2T-I)			VCDA	
TRW MY 03 AirBag (2F-2P-I)	VCDA			

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
		1.9 JTD	Engine-Gearbox	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)
	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)			VCDAS027
	Instrumentation		Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
	Safety		Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
	Comfort		TRW MY 03 AirBag (2F-2P-I)	VCDA
			Denso Climate Control 1 (Two-zone)	VCDAS022
		Marelli/Microsoft Convergence	VCDAS004	
TRW 3 Electric Steering		VCDS008		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions	
		Other systems	G.E.PROCOND boot	VCDA	
			G.E.PROCOND Driver's Door	VCDA	
			G.E.PROCOND Passenger Door	VCDA	
			Single BITRON Driver's Door	VCDA	
			Single Driver's Door G.E. PROCOND	VCDA	
			Valeo Parking control unit	VCDS023	
	2.0 16V	Engine-Gearbox	Magneti Marelli MM4MP2 PSA Injection	VCDA	
			Magneti Marelli MM6LP PSA Injection	VCDAS053	
			Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054	
		Instrumentation	Marelli DAV PSA Connect control	VCD	
			Marelli odometer w. lamps (BTO)	VCDA	
			Marelli PSA Connect	VCDAS028	
			Marelli PSA instrument panel	VCDA	
			Sagem multi-function screen	VCDA	
		Safety	Bosch 5.7 ESP PSA ABS	VCDAS052	
			Sagem Body Computer	VCDAS029	
			Temic airbag	VCDS030	
			Texton alarm 2	VCDA	
		Comfort	Bitron PSA driver's seat	VCDA	
			Clarion CD Changer	VCDA	
			Clarion/Philips sound system	VCDAS031	
			Marelli PSA climate control	VCDA	
				Eaton multi-switch stalk unit (COM2000)	VCD
				Inalfa central sunroof	VCDAS084
				Inalfa front sunroof	VCDAS084

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Other systems	Inalfa rear sunroof	VCDAS084
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
	2.0 JTD 16V	Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
			Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054
		Instrumentation	Marelli DAV PSA Connect control	VCD
			Marelli odometer w. lamps (BTO)	VCDA
			Marelli PSA Connect	VCDAS028
			Marelli PSA instrument panel	VCDA
			Sagem multi-function screen	VCDA
		Safety	Bosch 5.7 ESP PSA ABS	VCDAS052
			Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
WEBASTO Heater (PSA)	VCDA			
	Eaton multi-switch stalk unit (COM2000)	VCD		
	Inalfa central sunroof	VCDAS084		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
PHEDRA		Other systems	Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli diesel additive check	VCDAS034
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
			2.2 JTD 16V	Engine-Gearbox
	Instrumentation	Marelli DAV PSA Connect control		VCD
		Marelli odometer w. lamps (BTO)		VCDA
		Marelli PSA Connect		VCDAS028
		Marelli PSA instrument panel		VCDA
		Sagem multi-function screen		VCDA
	Safety	Bosch 5.7 ESP PSA ABS		VCDAS052
		Sagem Body Computer		VCDAS029
		Temec airbag		VCDS030
		Texton alarm 2		VCDA
	Comfort	Bitron PSA driver's seat		VCDA
		Clarion CD Changer		VCDA
		Clarion/Philips sound system		VCDAS031
		Marelli PSA climate control	VCDA	
WEBASTO Heater (PSA)		VCDA		
		Eaton multi-switch stalk unit (COM2000)	VCD	

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Other systems	Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli diesel additive check	VCDAS034
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
			3.0 V6 24V	Engine-Gearbox
	ZF 4HP20 PSA Automatic Gearbox	VCD		
	Instrumentation	Marelli DAV PSA Connect control		VCD
		Marelli odometer w. lamps (BTO)		VCDA
		Marelli PSA Connect		VCDAS028
		Marelli PSA instrument panel		VCDA
		Sagem multi-function screen		VCDA
	Safety	Bosch 5.7 ESP PSA ABS		VCDAS052
		Sagem Body Computer		VCDAS029
		Temec airbag		VCDS030
		Texton alarm 2		VCDA
	Comfort	Bitron PSA driver's seat		VCDA
		Clarion CD Changer		VCDA
		Clarion/Philips sound system		VCDAS031
		Marelli PSA climate control		VCDA

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDAS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
		Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
			Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054
			Siemens Diesel Injection SID803 CF4/EOBD (eng. 16v)	VCDAS036
		Instrumentation	Johnson/Borg multi-function screen	VCDAS073
			Marelli odometer warning lamps (BTO CAN)	VCDA
			PSA DAV Connect Command (CAN)	VCD
			PSA Marelli Connect (CAN)	VCDAS085
			Marelli Connect PSA RT5 (CAN)	VCDAS082
		Safety	PSA Marelli cluster (CAN)	VCDA
			Bosch ABS 8.1 ESP PSA (CAN)	VCDAS070
			Johnson EV Body Computer (BSI CAN) 2	VCDAS088
			BOSCH/TEMIC Airbag (CAN)	VCDAS071
			PSA Bosch ABS 8 ESP (CAN)	VCDAS083
			Delphi Alarm	VCDAS072
			Blaupunkt radio	VCDA

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
PHEDRA (180)	2.0 JTD 16v	Comfort	PSA Denso Climate Control (CAN)	VCDAS062
			WEBASTO Heater (PSA)	CDA
		Other systems	Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Delphi multi-function switch (COM2005)	VCDAS063
			Brose Driver's Door	VCDAS063
			Brose passenger door	VCDAS063
			Delphi multi-SWITCH (COM2003)	VCDAS063
			Inalfa centre sunroof (CAN)	VCDAS063
			Inalfa front sunroof (CAN)	VCDAS063
			Inalfa rear sunroof (CAN)	VCDAS063
			Marelli Diesel additive control (CAN)	VCDAS087
			Siemens Tyre Pressure Control	VCDAS086
			Texton sliding doors (CAN)	VCDAS086
		PSA Valeo Parking Control Unit (CAN)	VCDAS086	
		Engine-Gearbox	AISIN AM6 Automatic Gearbox	VCDAS037
			Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	VCDAS038
			Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
		Instrumentation	Johnson/Borg multi-function screen	VCDAS073
			Marelli odometer warning lamps (BTO CAN)	VCDAS073
Marelli Connect PSA RT5 (CAN)	VCDAS082			
PSA DAV Connect Command (CAN)	VCDAS082			
PSA Marelli Connect (CAN)	VCDAS085			
	PSA Marelli cluster (CAN)	VCDAS085		
	Bosch ABS 8.1 ESP PSA (CAN)	VCDAS070		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	2.2 JTD 16V	Safety	Johnson EV Body Computer (BSI CAN) 2	VCDAS088
			BOSCH/TEMIC Airbag (CAN)	VCDAS071
			PSA Bosch ABS 8 ESP (CAN)	VCDAS083
			Delphi Alarm	VCDAS072
		Comfort	Blaupunkt radio	VCDA
			PSA Denso Climate Control (CAN)	VCDA
			WEBASTO Heater (PSA)	CDA
		Other systems	Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Brose Driver's Door	VCDA
			Brose passenger door	VCDA
			Delphi multi-SWITCH (COM2003)	VCDA
			Inalfa centre sunroof (CAN)	VCDA
			Inalfa front sunroof (CAN)	VCDA
			Inalfa rear sunroof (CAN)	VCDA
			Marelli Diesel additive control (CAN)	VCDAS087
			Siemens Tyre Pressure Control	VCDAS086
			Texton sliding doors (CAN)	VCDA
			PSA Valeo Parking Control Unit (CAN)	VCDA
		Engine-Gearbox	Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors)	VCDAS001
ESP TRW Lucas ABS	VCDAS013			
Safety	Marelli Easy-go Body computer	VCDAS046		
	Marelli Full Body computer	VCDAS046		
	TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD		
	TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	2.0 20V TB	Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	2.4 20V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDA001
		Safety	ESP TRW Lucas ABS	VCDA013
			Marelli Easy-go Body computer	VCDA046
			Marelli Full Body computer	VCDA046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
		Comfort	TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
			Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
		Other systems	SAGEM SpeedPro power steering	VCD
			Marelli Boot	VCDA
Marelli Driver's Door	VCDA			
Marelli Passenger Door	VCDA			
Engine-Gearbox	Valeo Parking control unit	VCDS023		
	Bosch EDC15 CF3/EOBD Diesel injection (eng. 1.9/2.4)	VCDA016		
	ESP TRW Lucas ABS	VCDA013		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
THESIS	2.4 JTD 10V	Safety	Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	2.4 JTD 20V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	VCDAS039
			Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	VCDAS040
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)			VCD	
Comfort		Bitron driving seat	VCDA	
		Bitron passenger seat	VCDA	
		Borletti/Hella climate control	VCDS089	
	SAGEM SpeedPro power steering	VCD		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	3.0 V6 24V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic EOBD ME3.1 Injection (eng. V6)	VCDAS001
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	TRW MY 99 Airbag (2F-4P-I-S-C)	VCD
			Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
		Other systems	SAGEM SpeedPro power steering	VCD
			Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
		Engine-Gearbox	Valeo Parking control unit	VCDS023
			AISIN YLII 5 Automatic Gearbox	VCDA
		Instrumentation	Bosch Motronic ME7.3.1 EOBD Injection	VCDAS001
			Injection-Bosch Motronic Me7.3.1 Outside EEC	VCDAS001
				Nippon Seiki instrument panel (Thesis)

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	3.2 V6 24V	Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	1.1	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD	
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
		Allied MY 97 Airbag (2F-2P-I)	VCD	
		Bosch 5.3 ABS	VCD	
		Magneti Marelli IAW 16F Injection	VCD	
		1.2	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
	Allied MY 97 Airbag (2F-2P-2L-I)		VCD	
	Allied MY 97 Airbag (2F-2P-I)		VCD	
	Bosch 5.3 ABS		VCD	
	Fuji MX665 Automatic Transmission (EEC2 engine)		VCD	
	Magneti Marelli IAW 16F Injection		VCD	
			Allied MY 97 Air Bag (2F-2P-2L-S)	VCD

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Y	1.2 16V	Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
	1.2 16V CF3	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Motronic ME7.3H4 EOBD injection	VCDAS001
	1.2 CF3	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Air Bag (2F-2P-S)	VCD
		Allied MY 97 Airbag (2F-2P)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Fuji MX665 Automatic Transmission (EEC2 engine)	VCD
	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014	
1.4	Allied MY 97 Airbag (2F-2P)	VCD	
	Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
	Allied MY 97 Airbag (2F-2P-I)	VCD	
	Bosch 5.3 ABS	VCD	
	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
	Instrumentation	Marelli 3 Connect (multi-model)	VCDA
		Siemens instrument panel	VCDAS058
		Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
		Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.2 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	Bitron Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
	Single BITRON Driver's Door		VCDA	
	Single Driver's Door G.E.PROCOND		VCDA	
		Engine-Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
			Instrumentation	Marelli 3 Connect (multi-model)
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)			VCDA	
Autoliv MY 99 Airbag (2F-2P-I)			VCDA	

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.2 8V		ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
	Single BITRON Driver's Door		VCDA	
	Single Driver's Door G.E.PROCOND	VCDA		
	1.3 JTD	Engine-Gearbox	Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	VCDAS018
			Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055
			Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)			VCDA	
Autoliv MY 99 Airbag (2F-2P-I)			VCDA	
ESP TRW Lucas ABS	VCDAS013			
Marelli/Finmek Body Computer	VCDAS041			

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
YPSILON			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDAS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E.PROCOND	VCDA
	1.4 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
Comfort	DELPHI Electric Steering	VCDAS044		
	Denso Climate Control (Two-zone)	VCDAS007		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions	
		Other systems	BITRON Driver's door	VCDAS042	
			BITRON passenger door	VCDAS042	
			Bosch Parking Control Unit	VCDAS042	
			G.E.PROCOND Driver's Door	VCDAS042	
			G.E.PROCOND Passenger Door	VCDAS042	
			Single BITRON Driver's Door	VCDAS042	
			Single Driver's Door G.E.PROCOND	VCDAS042	
	'06 1.2 8V	Engine-Gearbox	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014	
			Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014	
		Instrumentation	Marelli 3 Connect (multi-model)	VCDAS042	
			Siemens instrument panel	VCDAS058	
		Safety	ESP TRW Lucas ABS	VCDAS013	
			Marelli 7 Body Computer	VCDAS047	
			TRW Lucas ABS	VCDAS015	
		Comfort	DELPHI Electric Steering	VCDAS044	
			Denso Climate Control (Two-zone)	VCDAS007	
			Marelli/Microsoft Convergence	VCDAS004	
		Other systems	Bosch Parking Control Unit	VCDAS042	
		'06 1.3 JTD	Engine-Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055
				Marelli Diesel injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051
			Instrumentation	Marelli 3 Connect (multi-model)	VCDAS042
Siemens instrument panel	VCDAS058				
Safety	ESP TRW Lucas ABS		VCDAS013		
	Marelli 7 Body Computer		VCDAS047		
	TRW Lucas ABS		VCDAS015		

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
	'06 1.4 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
		'06 1.4 8V	Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)
	Instrumentation		Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
	Safety		ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
Comfort	DELPHI Electric Steering		VCDS044	
	Denso Climate Control (Two-zone)		VCDAS007	
	Marelli/Microsoft Convergence		VCDAS004	
Other systems	Bosch Parking Control Unit		VCDAS042	

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
YPSILON(402)	0.9 TURBO TWIN AIR	Engine-Gearbox	Automatic Gearbox Marelli SELESPEED CFC328 2	VCDAS066
			Magneti Marelli IAW 8GSF CF5/EOBD Injection (EP 0.9 engine)	VCDAS064
		Instrumentation	Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
		Safety	Bosch ABS 9 (EP)	VCDAS067
			Bosch ABS 9 ESP (EP)	VCDAS068
			Delphi (EP) 6 Body Computer	VCDAS076
			Bosch Air bag (EP)	VCDA
		Comfort	Denso Heater (EP)	VCDA
			DELPHI Electric Steering (EP) 4	VCDS078
			Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079
		Other systems	VALEO Parking Control unit (EP) 2	VCDAS069
	Litronic discharge headlamp (left)		VCDA	
	Litronic discharge headlamp (right)		VCD	
	Valeo Semi-Automatic Parking Control Unit (EP)		VCDAS080	
	1.2 8V	Engine-Gearbox	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8V)	VCDAS065
			Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	VCDAS074
		Instrumentation	Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
		Safety	Bosch ABS 9 (EP)	VCDAS067
Bosch ABS 9 ESP (EP)			VCDAS068	
Delphi (EP) 6 Body Computer			VCDAS076	
Bosch Air bag (EP)			VCDA	
Comfort		Denso Heater (EP)	VCDA	
		DELPHI Electric Steering (EP) 4	VCDS078	

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
		Other systems	Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079
			VALEO Parking Control unit (EP) 2	VCDAS069
			Litronic discharge headlamp (left)	VCDA
			Litronic discharge headlamp (right)	VCD
			Valeo Semi-Automatic Parking Control Unit (EP)	VCDAS080
	1.3 MJET 16V	Engine-Gearbox	Marelli Diesel Injection 8F3 CF5/EOBD (EP 1.3 JTD engine)	VCDAS075
		Instrumentation	Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
		Safety	Bosch ABS 9 (EP)	VCDAS067
			Bosch ABS 9 ESP (EP)	VCDAS068
			Delphi (EP) 6 Body Computer	VCDAS076
			Bosch Air bag (EP)	VCDA
		Comfort	Denso Heater (EP)	VCDA
			DELPHI Electric Steering (EP) 4	VCDS078
			Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079
		Other systems	VALEO Parking Control unit (EP) 2	VCDAS069
			Valeo Semi-Automatic Parking Control Unit (EP)	VCDAS080
Z	'00 2.0 16v	Magneti Marelli MM4.8P PSA injection	VCDA	
	'00 2.0 JTD	Bosch EDC 15 PSA Diesel Injection (2.0 8v v60 eng.)	VCDA	
		Bosch EDC 15 PSA Diesel Injection (eng. 16v)	VCDAS033	
		Bosch EDC 15 PSA Diesel Injection (eng. 2.0 8v)	VCDA	
		WEBASTO Heater (PSA)	VCDA	

(*):Tested;

(?):Manual on website(www.x431.com)

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
--------	--------------	---------	-----------

N. B. :

V: Control Unit Info

C: Fault Codes

D: Datastream

A: Active Test

S: Additional Functions

S001	Startup with Code Card
S002	Startup with Code Card
S002	Performance limiting
S002	Neutral signal learn
S002	Knock counter reset
S002	Overboost counter reset
S002	Self-learnt functions reset
S002	Zeroing of self-adaption parameters
S003	Headlamp pos. correct.
S003	Inputs status
S003	Servicing information delete
S003	Reset odometer
S003	Seat belts alarm exclusion
S003	Seat belts alarm enable
S003	Oil change servicing information delete
S003	Instrument panel replacement
S004	Audio System Test

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S004			Convergence system Restart
S005			Siren Serial line check
S005			Ultrasound sensor check
S005			Tilt sensor check(if present)
S005			Dusk and rain sensors check
S005			Indicators command enable/disable
S005			Inertia switch rearm(FIS)
S005			Key programming
S006			Yaw sensor calibration
S006			Lateral accel. Sensor calibration
S006			Pressure sensor calibration
S006			Accept configuration
S006			Longit. Acc. Sensor calibration
S006			Accelerat. And yaw sensors calibration
S006			Recognition of speed sensor type
S007			Conditioner compressor
S007			Flap actuators learning test
S007			Pollution sensor test
S007			Autotest
S008			Steering angle calibration
S008			Mounting check
S009			Startup with Code Card
S009			Injector codes read
S009			Neutral signal learn
S009			Replacement of injector cyl.1

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S009			Replacement of injector cyl.2
S009			Replacement of injector cyl.3
S009			Replacement of injector cyl.4
S009			Injector replacement(per bank)
S009			Oil change(only for version with DPF)
S009			EGR valve replacement
S009			Variable geometry turbo replacement
S009			Rail pressure sensor replacement
S009			Replacement Lambda sensor
S009			Air flow meter sensor replacement
S009			Differential pressure sensor replacement(only for version with DPF)
S009			Pre-catalyser replacement(only for version with DPF)
S009			Particulate filter replacement (only for version with DPF)
S009			Replacement of particulate filter with built-in pre-catalyzer(only for versions with DPF)
S009			Particulate filter regeneration(only for version with DPF)
S009			Resetting distance travelled with Water Temp.w.lamp ON
S009			Resetting distance travelled with Water in diesel w.lamp ON
S010			Accumulator depressurisation
S010			Clutch bleed
S010			End of line / service self-calibration
S010			Clutch self-calibration enable
S010			New actuators
S010			Satistical data deletion
S010			Clutch replacement
S010			KIT/Gearbox replacement

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S010			Gearbox replacement
S010			Tunnel lever replacement
S010			Steering wheel levers replacement
S010			Electropump replacement
S010			Pump relay replacement
S010			AUTO switch replacement
S010			ECO/SPORT switch replacement
S010			Gearbox oil accumulator replacement
S010			Longitudinal acceleration signal learn
S011			Gearbox lever position learn
S011			Self-adaptation parameter erasure
S012			Startup with Code Card
S012			Oil change
S012			Knock counter reset
S012			Overboost counter reset
S012			Self-learnt functions reset
S012			Zeroing of self-adaptation parameters
S013			Steering angle calibration
S013			Yaw sensor calibration
S013			Lateral accel. Sensor calibration
S013			Pressure sensor calibration
S013			Accept configuration
S013			Longit. Acc. Sensor calibration
S014			Startup with Code Card
S014			Lambda sensor check

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S015			Accept configuration
S016			Startup with Code Card
S016			Injector classification
S017			Accumulator depressurisation
S017			Clutch bleed
S017			End of line / service self-calibration
S017			Clutch self-calibration enable
S017			Calculation of clutch degradation index
S017			Gearbox replacement
S017			Hydraulic Kit replacement
S017			Gearbox and hydraulic KIT replacement
S017			Clutch replacement
S017			Tunnel lever replacement
S017			Electropump replacement
S017			Pump relay replacement
S017			ECO switch replacement
S017			Gearbox oil accumulator replacement
S017			Selection and/or engagement clutch electrovalve replacement
S017			Longitudinal acceleration signal learn
S018			Startup with Code Card
S018			Self-learnt functions reset
S018			Injector codes read
S018			Cyl.1 injector classification
S018			Cyl.2 injector classification
S018			Cyl.3 injector classification

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S018	Cyl.4 injector classification		
S018	Injector classification (4 cyl.blank)		
S019	Startup with Code Card		
S019	Injector codes read		
S019	Neutral signal learn		
S019	Replacement of injector cyl.1		
S019	Replacement of injector cyl.2		
S019	Replacement of injector cyl.3		
S019	Replacement of injector cyl.4		
S019	Injector replacement(per bank)		
S019	Oil change		
S019	Rail pressure sensor replacement		
S019	Replacement Lambda sensor		
S019	Air flow meter sensor replacement		
S019	Phonic wheel replacement		
S019	Differential pressure sensor replacement		
S019	Particulate filter with integrated pre-cat replacement		
S019	Particulate filter regeneration		
S019	Mechanical waste-gate valve replacement		
S019	Replacement of variable geometry turbo and/or turbo posit. Sensor		
S019	Resetting distance travelled with Water Temp. w. lamp ON		
S019	Resetting distance travelled with Water in diesel w. lamp ON		
S020	Headlamp pos. correct.		
S020	Inputs status		
S020	Servicing information delete		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S020			Reset odometer
S020			Seat belts alarm exclusion
S020			Seat belts alarm Enable
S020			Instrument panel replacement
S021			Headlamp pos. correct
S021			Inputs status
S021			Reset odometer
S021			Seat belts alarm exclusion
S021			Seat belts alarm enable
S021			Instrument panel replacement
S022			Flap actuators learning test
S022			Pollution sensor test
S023			Tow hook presence disable
S023			Tow hook presence enable
S024			Accumulator depressurisation
S024			Clutch bleed
S024			End of line / service self-calibration
S024			Clutch self-calibration enable
S024			New actuators
S024			Calculation of clutch degradation index
S024			Statistical data deletion
S024			Clutch replacement
S024			KIT/Gearbox replacement
S024			Gearbox replacement
S024			Tunnel lever replacement

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S024			Electropump replacement
S024			Pump relay replacement
S024			ECO switch replacement
S024			Gearbox oil accumulator replacement
S024			Longitudinal acceleration signal learn
S025			Startup with Code Card
S025			Phonic wheel learn reset
S025			Zeroing of self-adaption parameters
S025			Throttle learn storage
S025			Vehicle configuration deletion
S025			Cruise Control Learn
S025			Air conditioner Learn
S025			Phase sensor learn zeroing
S026			Startup with Code Card
S026			Injector codes read
S026			Cyl.1 injector classification
S026			Cyl.2 injector classification
S026			Cyl.3 injector classification
S026			Cyl.4 injector classification
S026			Injector classification (4 cyl.blank)
S027			Startup with Code Card
S027			Injector codes read
S027			Replacement of injector cyl. 1
S027			Replacement of injector cyl. 2
S027			Replacement of injector cyl. 3

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S027	Replacement of injector cyl. 4		
S027	Replacement injectors (4 cyl. Bank)		
S027	Control unit replacement		
S027	Replacement of control unit and injector/s		
S027	Air flow sensor replacement		
S027	Replacement Lambda sensor		
S027	Rail pressure sensor replacement		
S027	Rail pressure sensor and injector/s replacement		
S028	Voice synthesis test		
S028	Cooling fans test		
S028	Automatic emergency call activation		
S028	Manual emergency call activation		
S028	Assistance call activation		
S028	Optical fibre test		
S028	Backup battery replacement		
S028	Personal data deletion		
S028	VIN Code Configuration		
S028	Call buttons Configuration		
S028	Manual System Configuration		
S028	Automatic Configuration Read		
S028	Activation/Deactivation 'Auxiliary video input' procedure		
S029	Dist. To Next Service Zeroing (Coupon)		
		Wheel transmitters learning	
S029	Tyre Pressure check	Looks for faulty wheel transmitter	
		Looks for flat battery on wheel transmitter	

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S029	New vehicle preparation	Maintenance Services config. Customer mode Reset distance till next servicing	
S029	Control Unit Replacement	Customer options Key programming Closure / Safety Engine / Gearbox Lights / Visibility	
S029	Manual System Configuration	Various Driver warnings Select the type of vehicle	
S030	System Configuration Read		
S031	Chassis number		
S032	Stored status deletion		
S033	Part. Filter regeneration		
S034	FAP Replacement		
S034	Additive type configuration		
S034	FAP Temperature Probe presence configuration		
S035	Zeroing of self-adaption parameters		
S036	Additional diesel circuit filling		
S036	Replacement of the additive,or the pump,or the tubes.		
S036	Particulate filter replacement (only for version with DPF)		
S036	EGR valve learn		
S036	Part. Filter regeneration		
S036	Replacement injector/s		

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S037			Automatic gearbox replacement
S037			Automatic gearbox and Control unit replacement
S037			Automatic gearbox oil replacement
S038			Part. Filter regeneration
S039			Startup with Code Card
S039			Injector codes read
S039			Replacement of injector cyl. 1
S039			Replacement of injector cyl. 2
S039			Replacement of injector cyl. 3
S039			Replacement of injector cyl. 4
S039			Replacement injector cyl. 5
S039			Injector replacement (per bank)
S039			Oil change (only for version with DPF)
S039			Rail pressure sensor replacement
S039			Lambda sensor replacement (only for version with lambda sensor)
S039			Air flow meter replacement (only for version with lambda sensor)
S039			Differential pressure sensor replacement (only for version with DPF)
S039			Pre-catalyser replacement (only for version with DPF)
S039			Particulate filter replacement (only for version with DPF)
S039			Particulate filter regeneration (only for version with DPF)
S040			Startup with Code Card
S040			Injector codes read
S040			Cyl. 1 injector classification
S040			Cyl. 2 injector classification
S040			Cyl. 3 injector classification

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S040	Cyl. 4 injector classification		
S040	Cyl.5 injector classification		
S040	Injector classification (4 cyl. blank)		
S040	Injector classification (5 cyl. blank)		
S041	Siren serial line check		
S041	Ultrasound sensor check		
S041	Tilt sensor check (if present)		
S041	Dusk and rain sensors check		
S041	Window wash system check		
S041	Country Standards Change		
S042	Sensor vibration time too long		
S043	Accumulator depressurisation		
S043	Clutch bleed		
S043	End of line / service self-calibration		
S043	Clutch self-calibration enable		
S043	New actuators		
S043	Calculation of clutch degradation index		
S043	Satistical data deletion		
S043	Data deletion and return to initial values for clutch replacement		
S043	Data deletion for KIT/Gearbox replacement		
S043	Data deletion for tunnel lever replacement		
S043	Data deletion for pump replacement		
S043	Data deletion for KIT/Pump replacement		
S043	Data deletion for pump relay replacement		
S043	Deletion of statistical data relating to errors		

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S044			Servo Mechanism Group Replacement
S044			Engine - Control Unit Group Replacement
S045			Steering angle calibration
S045			Longit.acc.sensor calibration
S046			Siren serial line check
S046			Ultrasound sensor check
S046			Tilt sensor check(if present)
S046			Dusk and rain sensors check
S046			Window wash system check
S047			Dusk and rain sensors check
S047			Window wash system check
S048			next service km's reset
S048			Light setting corr.
S048			trip counter reset
S049			Startup with Code Card
S049			Zeroing of self-adaption parameters
S050			Electronic Key release
S050			EGR
S051			Startup with Code Card
S051			Replacement of injector cyl. 1
S051			Replacement of injector cyl. 2
S051			Replacement of injector cyl. 3
S051			Replacement of injector cyl. 4
S051			Oil change (only for version with DPF)
S051			Phonic wheel replacement

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S051			Rail pressure sensor replacement
S051			Lambda sensor replacement (only for version with lambda sensor)
S051			Air flow meter replacement (only for version with lambda sensor)
S051			Differential pressure sensor replacement (only for version with DPF)
S051			Pre-catalyser replacement (only for version with DPF)
S051			Particulate filter replacement (only for version with DPF)
S052			Steering angle calibration
S052			Test limit speed disable
S052			Test limit speed restore
S052			Brake bleed
S053			Reset self-adapt. param. and idle act
S054			Oil Counter Write
S054			Self-adaptive parameters
S054			Sequence EV. 1
S054			Sequence EV. 2
S054			Sequence EV. 3
S054			Sequence EV. 4
S054			Sequence EV. 5
S054			Sequence EV. 6
S054			Heat exchang. Flow EV.
S055			Accumulator depressurisation
S055			Clutch bleed
S055			End of line / service self-calibration
S055			Clutch self-calibration enable
S055			New actuators

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S055			Calculation of clutch degradation index
S055			Engagement lever pin securing screw diagnosis
S055			Selection lever return diagnosis
S055			Satistical data deletion
S055			Deletion of statistical data relating to errors
S055			Data deletion and return to initial values for clutch replacement
S055			Data deletion for KIT/Gearbox replacement
S055			Data deletion for tunnel lever replacement
S055			Data deletion for pump replacement
S055			Data deletion for KIT/Pump replacement
S055			Data deletion for pump relay replacement
S055			Deletion of CITY switch replacement data
S055			Deletion of SPORT switch replacement data
S055			Data deletion for steering wheel levers replacement
S056			Tow hook presence disable
S056			Tow hook presence enable
S056			Parking manoeuvre status
S057			Antenna replacement
S057			Control unit replacement
S057			Alarm deletion
S057			Wheel transmitters learning
S057			Control unit activation
S057			Control unit deactivation
S057			Alarm state check
S058			Headlamp pos.correct.

LANCIA V16.22 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S058			Servicing information delete
S058			Reset odometer
S058			Seat belts alarm exclusion
S058			Seat belts alarm Enable
S058			Instrument panel replacement
S059			Tow hook presence disable
S059			Tow hook presence enable
S060			Reset odometer
S060			Servicing information delete
S060			Odometer write
S060			Intrument panel replacement
S061			Steering angle calibration
S061			Vehicle type learn reset
S062			Headlight actuators - high
S062			Headlight actuators - intermediate
S062			Headlight actuators - low
S062			System calibration
S063			Headlight actuators - high
S063			Headlight actuators - intermediate
S063			Headlight actuators - low
S063			System calibration
S064			Startup with Code Card
S064			Self - learnt functions reset
S064			Zeroing of self - adaption parameters
S064			Neutral signal learn

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S064			Performance limiting deactivation
S064			Oil change
S064			Motorised throttle replacement
S064			MultiAir Rolling finger replacement
S064			Timing sensor and/or cam replacement
S064			Rpm sensor and/or timing chain replacement
S064			Oil temperature sensor replacement
S064			Phonic wheel replacement
S064			UniAir module replacement
S064			Intelligent alternator (IAM) replacement
S064			Supercharging system components replacement
S064			Downstream lambda sensor and/or catalyzer and/or Injectors replacement
S065			Startup with Code Card
S065			Throttle learn storage
S065			Vehicle configuration deletion
S065			Phonic wheel learn reset
S065			Zeroing of self-adaption parameters
S065			Cam edges zeroing(VVT)
S065			Neutral signal learn
S066			Self-learnt functions reset
S066			Pump relay replacement
S066			Tunnel lever replacement
S066			Steering wheel levers replacement
S066			AUTO switch replacement
S066			ECO/SPORT switch replacement

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S066			Clutch self-calibration enable
S066			Accumulator depressurisation
S066			New actuators
S066			Clutch bleed
S066			End of line/service self-calibration
S066			Longitudinal acceleration signal learn
S067			Static test
S068			Static test
S068			Lateral and longitud.acceleration sensor calibration
S068			Steering angle calibration
S068			Longitudinal/lateral Accel.sens.Calibration reset
S069			Tow hook presence disable
S069			Tow hook presence enable
S070			Brake bleed
S070			Steering angle calibration
S070			Steering angle reset
S070			Longit. acc. sensor calibration
S071			System Configuration Read
S071			control Unit Unlock
S072			Manual System Configuration
S072			Automatic Configuration Read
S072			Automatic Configuration Write
S072			United Kingdom(Thatcham std)
S072			Volumetric sensors automatic diagnosis
S073			Manual System Configuration

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S073			Deletion stored buttons
S073			Automatic Configuration Read
S073			Automatic Configuration Write
S074			Startup with Code Card
S074			Throttle learn storage
S074			Vehicle configuration deletion
S074			Phonic wheel learn reset
S074			Zeroing of self-adaption parameters
S074			Cam edges zeroing(VVT)
S075			Startup with Code Card
S075			Injector codes read
S075			Speed limit setting
S075			Neutral signal learn
S075			Replacement of injector cyl. 1
S075			Replacement of injector cyl. 2
S075			Replacement of injector cyl. 3
S075			Replacement of injector cyl. 4
S075			Injector replacement(per bank)
S075			Oil change
S075			Phonic wheel replacement
S075			Rail pressure sensor replacement
S075			Replacement lambda sensor
S075			Air flow meter sensor replacement
S075			Differential pressure sensor replacement
S075			Particulate filter with intergrated pre-cat replacement

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S075			Particulate filter regeneration
S075			Intelligent alternator (IAM) replacement
S075			Mechanical waste-gate valve replacement
S075			Replacement of variable geometry turbo and/or turbo posit. Sensor
S075			Resetting distance travelled with Water Temp. w. lamp ON
S075			Resetting distance travelled with Water in diesel w. lamp ON
S075			EGR valve test
S075			Throttle test
S075			Glow plug preheating circuit test
S075			Self-learnt functions reset
S076			Windowscreen wiper relay speed 1
S076			Windowscreen wiper relay speed 2
S076			Driver's side wind. Lift. Motion
S076			Pass. Side wind. Lift. Motion
S076			Inertia switch rearm (FIS)
S076			Indicators command enable/disable
S076			Country Standards Change
S076			Power Mode Gearbox
S077			Headlamp pos. correct
S077			Servicing information delete
S077			Reset odometer
S077			Seat belts alarm exclusion
S077			Seat belts alarm Enable
S077			Instrument panel replacement
S078			Position sensor calibration

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S079			Flap actuators learning test
S080			Tow hook presence disable
S080			Tow hook presence enable
S080			Parking manoeuvre status
S081			Audio System Test
S081			Convergence System Restart
S082			Cooling fans test
S082			Automatic emergency call activation
S082			Manual emergency call activation
S082			Assistance call activation
S082			Backup battery replacement
S082			Personal data deletion
S082			JukeBox data deletion
S082			VIN Code Configuration
S082			Call buttons Configuration
S082			Manual System Configuration
S082			Automatic Configuration Read
S082			Automatic Configuration Write
S083			Brake bleed
S083			Steering angle calibration
S083			Steering angle reset
S084			System configuration
S085			Voice synthesis test
S085			Cooling fans test
S085			Automatic emergency call activation

LANCIA V16.22 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S085			Manual emergency call activation
S085			Assistance call activation
S085			Optical fibre test
S085			Backup battery replacement
S085			Personal data deletion
S085			VIN Code Configuration
S085			Call buttons configuration
S086			Looks for faunty wheel transmitter
S086			Wheel transmitters learning
S086			Wheel identification check
S086			Control unit deactivation
S086			Control unit activation
S087			FAP Replacement
S087			Control unit replacement
S087			Engine type configuration
S088			Dist. To Next Service Zeroing(Coupon)
S089			Flap actuators learning test
S089			Pollution sensor test