

Nissan V41.80 Diagnostics List (Note: For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)

F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER, LDW:LANE CAMERA, AFS:ADAPTIVE LIGHT, NATS:NATS IMMU, SE:SMART ENTRANCE, AIRL:AIR LEVELIZER, RCM:REARVIEW CAMERA, SCM:S/BLIND CAMERA, AEM:ACTIVE ENG MOUNT, AS:ACTIVE SUS, ASCD:Auto Speed Control Device, CGC:CHG COMM, TETC:TK_ECU_TYPE_CLUCH, DC:DISTANCE CONTROL, MA:MOTOR ASSIST, IVMS:Integrated Voice-Messaging System, TQC:TORQ CONT, AP:ACCELE PEDAL, CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPA NT	MULTI DISP	SVT					
ALTIM A	L31	2001 2002 2003 2004 2005 2006*	SC		SC																																															
ALTIM A	L30	1997 1998 1999 2000*	SC		SC																																															
ALTIM A Hybrid	L32	2007 2008 2009 2010 2011	SC		SC																																															
ARMA DA	TA60	2003 2004 2005 2006 2007 2008 2009 2010 2011	SC		SC																																															

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Brak Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT							
INFINITI G37 Coupe	CV36	2007	SC																																																			
		2008	D		SC																																																	
		2009	F1	SC	D																		SC	SC																														
		2010	F2	D	T	SC				SC													D	D	SC																													
		2011	F3	F1	F1	D					D		SC										D	D	SC																													
INFINITI G37 Sedan	V36	2008	SC																																																			
		2009	D		SC																																																	
		2010	F1	SC	D																		SC	SC																														
		F2	D	T	SC					SC													D	D	SC																													
		F3	F1	F1	D						D		SC										D	D	SC																													
INFINITI I30	CA32	1996	SC																																																			
		1997	D		SC																																																	
		1998	F1	SC	D																																																	
		1999	F2	D	T	SC																																																
		2001	F3	F1	F1	D							SC																																									
INFINITI I35	CA33	2002	SC																																																			
		2003	D		SC																																																	
		2004	F1	SC	D																																																	
		F2	D	T	SC																																																	
		F3	F1	F1	D																																																	

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT						
JUKE	F15	2010 2011	SC D T F1 F2 F3 F4 F7 F8		SC D T F1 F2 F3	SC D T F1 F2 F3				SC D T F2 F3			SC D T F3																																								
MAXI MA	A35	2008 2009 2010 2011	SC D T F1 F2 F3 F4 F7 F8		SC D T F1 F2 F3	SC D T F1 F2 F3				SC D T F2 F3			SC D T F3																																								
MAXI MA	A34	2003 2004 2005 2006 2007 2008	SC D T F1 F2 F3 F4 F7 F8		SC D T F1 F2 F3	SC D T F1 F2				SC D T D			SC D T F2		SC D T F2																																						
MAXI MA	A33	1998 1999 2000 2001 2002 2003*	SC D T F1 F2 F3 F4 F7 F8		SC D T F1 F2 F3	SC D T F1 F2				SC D T D			SC D T F2		SC D T F2																																						

Nissan V41.80 Diagnostics List(Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UP ANT	MULTI DISP	SVT								
XTERRA	N50	2005	SC																																																				
		2006	D																																																				
		2007	T	SC	SC																																																		
		2008	F1	D	D																																																		
		2009	F2	F1	T	SC																		SC	SC																														
		2010	F3	F2	F1	D							SC											SC	D	D																													
ALMERA	N16	2009*	SC																																																				
			D																																																				
			T	SC	D	SC																																																	
			F1	SC	D	SC																																																	
			F2	D	T	SC																																																	
			F3	F1	F1	D																																																	
ALMERA	N15	*	SC																																																				
			D																																																				
			T	SC	D	SC																																																	
			F1	SC	D	SC																																																	
			F2	D	T	SC																																																	
			F3	F1	F1	D																																																	
ALMERA CLASSIC	B10	2006	SC																																																				
			D																																																				
			T	SC	D	SC																																																	
			F1	SC	D	SC																																																	
			F2	D	F1	SC																																																	
			F3	F1	F2	SC																																																	

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)

F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPANT	MULTI DISP	SVT					
CABSTAR	F24	2006 2007 2008 2009	SC D T F1 F2 F3 F4 F7 F8		SC D D T F1 F2 F3 F7								SC D T F3										CD F7																													
CABSTAR E	TLO	1998 2001	SC D T F1 F2 F3 F4 F7 F8		SC D T D F1 F2 F3 F7							SC D T F3	SC D T F2	SC D T F2	SC D T F2	SC D T F2	SC D T F2			SC D T F2		SC D T F2																									SC D T F2					
INFINITI EX35/EX30d	J50	2009 2010 2011	SC D T F1 F2 F3 F4 F7 F8		SC D T D F1 F2 F3 F7				SC D T F2			SC D T F3									SC D T F3			SC D T F3																										SC D T F2		
INFINITI EX37	J50	2008 2009	SC D T F1 F2 F3 F4 F7 F8		SC D D T F1 F2 F3 F7				SC D T F2			SC D T F3																																								SC D T F2

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT			
INFINITI FX37/FX50	S51	2008-2009	SC D T		SC D D SC D				SC D T				SC D D D	SC D D	SC D						SC D T	SC D T																	SC D T											
INFINITI FX37/FX50/FX30d	S51	2009-2010	SC D T		SC D D SC D				SC D T				SC D D D	SC D D	SC D						SC D T	SC D T	SC D T		SC D T																									
INFINITI M37/M56/M30d	Y51	2010-2011	SC D T		SC D D SC D				SC D D	SC D			SC D D D	SC D D	SC D						SC D T	SC D T	SC D T		SC D T																									
JUKE(2WD)	F15	2010	SC D T		SC D D SC D				SC D T	SC D			SC D D D	SC D D	SC D							SC D T																												

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPANT	MULTI DISP	SVT					
JUKE(4WD)	F15	2010	SC D T F1		SC					SC					SC	SC																																				
MAXI MA QX	A33	*	SC D T F1	SC	D	SC									SC	SC						SC																														
MAXI MA QX	A32	*	SC D T F1	SC	D	SC									SC	SC						SC																														
MICRA	K13	2010	SC D T F1	SC	D	SC									SC	SC						SC		SC																												

Nissan V41.80 Diagnostics List (Note: For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1, F2, F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	BreaK Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UP ANT	MULTI DISP	SVT									
NOTE	E11	2005 2006 2007 2009 2010	SC D T F1 F2 F3 F4 F7 F8		SC D F1 F2 F3 F7 F8	SC D F1 F2 F3 F7 F8	CD SC																																																	
NV200 (EURO product)	M20(VM20)	2010	SC D T F1 F2 F3 F4 F7 F8		SC D F1 F2 F3 F7 F8	SC D F1 F2 F3 F7 F8	CD SC					SC D F3	CD T																																											
NV200 (JPN product)	M20(VM20)	2009	SC D T F1 F2 F3 F4 F7 F8		SC D F1 F2 F3 F7 F8	SC D F1 F2 F3 F7 F8	CD SC					SC D F3	CD T																																											
PATROL	Y61	1997 1998 2000 2001 2002 2003 2004 2005 2006 2007 2009	SC D T F1 F2 F3 F4 F7 F8		SC D F1 F2 F3 F7 F8	SC D F1 F2 F3 F7 F8	CD F1 D D D																																																	

Nissan V41.80 Diagnostics List(Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、 F2、 F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SON AR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT													
Qashqai+2	J10	2008-2010	SC2 D2 T2 F12 F22 F32 F42 F72 F82		SC2 D2 T2										SC2	SC2						SC2 D2 T2 F22 F32																																						
SKYLINE	R34	*	SC2 D2 T2 F12 F22 F32 F42 F72 F82		SC2 D2 T2										SC2	SC2						SC2 D2 T2 F22 F32 F72																																						
SUNNY	Y10	*	SC2 D2 T2 F12 F22 F32 F42 F72 F82		SC2 D2 T2										SC2	SC2							SC2 D2 T2 F22 F32 F72																																					
TEANA	J32	2008-2010-2011	SC2 D2 T2 F12 F22 F32 F42 F72 F82		SC2 D2 T2										SC2								SC2 D2 T2 F22 F32																																					

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、 F2、 F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT																	
NV200 VANE TTE	M20(VM20)	2010	SC D T F1 F2 F3 F4 F7 F8		SC D SC D T F1 F2 F3																																																											
PALADIN	D22W	2003	SC D T F1 F2 F3 F4 F7 F8	SC D	SC D																																																											
PATHFINDER	WD21	*	SC D T F1 F2 F3 F4 F7 F8	SC D	SC D																																																											
SILVIA	S15	2000*	SC D T F1 F2 F3 F4 F7 F8	SC D	SC D																																																											

Nissan V41.80 Diagnostics List(Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT				
SUNN Y	N17	2010	SC																																																
SUNN Y	N15	*	SC																																																
SUNN Y	B15	*	SC																																																
SUNN Y	B14	*	SC																																																

Nissan V41.80 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info C:DTC--Read code & Clear code D:Data Stream T:Action Test F:Special Functions(F1、F2、F3.....)
 F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS ,
 ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCCUPA NT	MULTI DISP	SVT										
BASSARA	JU30	*	SCD D T		SCD D T																	SCD D																																			
CARAVAN	E25	2001	SCD D																																																						
		2002	D																																																						
		2003	T		SCD																																																				
		2004	F1	SCD	D	SCD																																																			
		2005	F2	D	T	SCD																																																			
		2007	F3	F1	F1	D																																																			
		2009	F4	F2	F2	T																																																			
		2010	F7	F3	F3	F1																																																			
				F8	F7	F7	F2		CD	SC	D	D	D	F3	T	F2	F2	F7	F2	CD	T	D	F2	F7	T	CD	F2	SC	F7	F2	F2	F2	F2	F7	F2	F2																					
		CEDRIC	Y31	1995	SCD D																																																				
1996	D																																																								
1998	T				SCD																																																				
1999	F1			SCD	D	SCD																																																			
2004	F2			D	T	SCD																																																			
2005	F3			F1	F1	D																																																			
2007	F4			F2	F2	T																																																			
2010	F7			F3	F3	F1																																																			
		F8	F7	F7	F2		CD	SC	D	D	D	F3	T	F2	F2	F7	F2	CD	T	D	F2	F7	T	CD	F2	SC	F7	F2	F2	F2	F7	F2	F2																								
CEDRIC/GLORIA	Y34		SCD D T		SCD																																																				
			F1	SCD	D	SCD																																																			
			F2	D	T	SCD																																																			
			F3	F1	F1	D																																																			
			F4	F2	F2	T																																																			
			F7	F3	F3	F1																																																			
			F8	F7	F7	F2																																																			
				F8	F7	F7	F2		CD	SC	D	D	D	F3	T	F2	F2	F7	F2	CD	T	D	F2	F7	T	CD	F2	SC	F7	F2	F2	F2	F7	F2	F2																						

